OfficeMaster Gate

Installation Worth knowing Configuration Advanced Configuration Appendix

User manual for administrators | Ferrari electronic AG

Copyright © 2017 Ferrari electronic AG

UNIFIED COMMUNICATIONS www.ferrari-electronic.com



OfficeMaster is a © 2017 Copyright fully owned by Ferrari electronic. All rights reserved. No part of this user manual must be reproduced without written consent. All trademarks within this manual are fully registered trademarks of the respective trademark owner. The document and software are both subject to changes.

We endeavoured to collect and describe information with best accuracy. However, we cannot exclude the possibility of minor faults within this manual. Ferrari electronic will not be held liable for mistakes and their consequences. Please address hints and comments to:

info@ferrari-electronic.de.

Ferrari electronic provides a forum for technical discussions and quick help. Access the forum at

http://forum.ferrari-electronic.de

Publisher: Ferrari electronic AG Ruhlsdorfer Str. 138 (DE) 14513 Teltow

Internet:www.ferrari-electronic.comPhone:+49 3328 455 90Fax:+49 3328 455 960E-Mail:info@ferrari-electronic.deAuthors:Johann Deutinger, Chris Helbing, Jeffrey Nimpadu

Correct as of 19.05.2017





Thank you for your trust in products of Ferrari electronic AG and your decision to use OfficeMaster.

Ferrari electronic is a leading German manufacturer of hardware and software for unified communications. The OfficeMaster range of products enhances all popular e-mail and application systems with functions for fax, SMS and voicemail. The hardware seamlessly connects a company's telecommunications infrastructure with the existing information technology. Customers benefit from greater efficiency and streamlined business processes.

We hope the product satisfies your companies needs entirely. In case of questions or suggestions please email:

info@ferrari-electronic.de



Table of content

1. Installation.	
1.1. ISDN Port	7
1.2. Network Integration	7
1.3. Installation of the Survivable Branch Appliance.	9
1.3.1. Rear view of server machine	9
1.3.2. Anatomy of the Media Gateway Board (MGB)	9
1.3.3. Analog Card – 4 Port (FXS)	
1.3.4. ISDN and Analog Interfaces	
1.4. Recovery	
1.4.1. Survivable Branch Appliance	
1.5. Stainless steel box - Restore to factory settings	14
1.6. Update and Upgrade	14
2. Worth knowing	
2.1. Offline Configuration	
2.2. Logging/Syslog	
2.3. Saving the configuration	19
2.4. Firmware update OfficeMaster Gate	19
2.5. Changing Password	20
2.6. License management	20
2.6.1. General settings	
2.6.2. Advanced settings	
3. Configuration	24
3.1. OfficeMaster Gate Basic Settings	
3.1.1. Connecting to OfficeMaster Gate	
3.1.2. Network configuration	
3.1.3. "Common"	27
3.1.4. Calls from ISDN	
3.1.5. Calls to ISDN	
3.1.6. Testing routing rules	
3.2. Configuration and Activation of OfficeMaster SBA	
3.2.1. Preparations in the central computing center	40
3.2.2. Installation OfficeMaster SBA	41
3.2.3. Media Gateway Configuration	46
3.2.4. Testing Media Gateway Routing for OfficeMaster SBA	
3.2.5. Display Event Logs and Syslog File	49
3.2.6. System Status	

3.3. OfficeMaster Gate and Lync Server 2010	50
3.3.1. Connection via TCP/RTP (not encrypted)	50
3.3.2. Configuring TLS/SRTP	
3.4. OfficeMaster Gate and Exchange Unified Messaging	61
3.4.1. Receiving Fax with Microsoft Exchange 2010	61
3.5. Drop & Insert – OfficeMaster Gate between Trunk and PBX	69
3.5.1. Inbound routing	69
3.6. Outbound routing	
4. Advanced Configuration	
4.1. Sign in at a SIP-Trunk	75
4.2. Registering SIP devices	
4.3. Settings for OfficeMaster SIP2Lync	
4.4. VoIP Parameter	
4.5. ISDN Parameter	82
4.6. ISDN-SIP Mapping	
4.7. Music on hold	85
Appendix A: Telephone number basics	ii
A.1. Rule based treatment of inbound calls	ii
A.2. Regular expressions	iii
A.3. Configuration examples	v



1. INSTALLATION

Network Integration

SBA

Update & Upgrade

User manual for administrators | Ferrari electronic AG

Copyright © 2017 Ferrari electronic AG

UNIFIED COMMUNICATIONS www.ferrari-electronic.com



1. Installation

1.1. ISDN Port

An important use of OfficeMaster Gate is as phone gateway for Microsoft's UC-systems. The Gateways passed the necessary certification tests for those systems and can therefore be used restrictive free - both as standalone Gateways and in combination with the OfficeMaster software, using the hardware and ISDN-ports together for all communication services (Fax, SMS, voice mail and telecommunication).

The communication can optionally take place encrypted (SIP/TCP, RTP) or unencrypted (SIP/TLS, SRTP).

Table 1.1: Signal flow on the ISDN ports

3	Rx+ (a2)	\rightarrow +	3
4	Tx+ (a1)	← +	4
5	Tx- (b1)	← -	5
6	Rx- (b2)	→ -	6
	1	→ +	1
	2	→ -	2
	4	← +	4
	5	← -	5

Located left and right below the BRI port of OfficeMaster Gate are two LED's. These are triggered by the firmware of the controller:

- The right hand side LED is triggered, when layer 1 of the ISDN protocol is activated.
- The left hand side is triggered, when the in-build ISDN terminating resistors are triggered via the configuration program.



Note! In older versions of the hardware, the left hand side LED is triggered, when the terminating is turned off! In all cases though, the settings in the configuration program apply.

Should an additional ISDN device be connected to the same BRI as OfficeMaster Gate it is mandatory that the ISDN port is declared as a multiple-device-port (point-to-multi point). When used in parallel connection, OfficeMaster Gate and others connected to this line need differing MSN (Multiple Subscriber Number) to be assigned to them. Is the ISDN line in point-to-point mode, no parallel connection is possible.

1.2. Network Integration

OfficeMaster Gate is addressed by the OfficeMaster Server-Software or, if used as media gateway, via the network. The Server-Software in this case is the component OMCUMS of the messaging server.

OfficeMaster Gate and OMCUMS communicate via TCP/IP. For this, they need to know each others IP addresses.



If used as media gateway, the communication with Microsoft servers occurs in the same way.

To make this possible, every OfficeMaster Gate is in need of a fitting network address. Possible ways of ensuring this:

With DHCP server

OfficeMaster Gate in delivery condition (standard, even after resetting) receives its IP-configuration from the in the network existing DHCP server. Via a DHCP server, IP-addresses and the Domain Name Server (DNS) are assigned to computers in the network.

In OMCUMS, the IP-address of OfficeMaster Gate is manually declared.

The uniqueness of the IP-addresses is ensured and an address conflict ruled out, because only one side requires a manual entry.

Without DHCP server

Is no DHCP server existing in the LAN or is the existing DHCP server not assigning an address to OfficeMaster Gate (because he for example is out of valid addresses), then OfficeMaster Gate will after a while automatically assign itself a private address (a so called Zeroconf-Address, also called APIPA-method). This address allows the activation of the build-in network interface, to ensure at least the availability via UDP broadcast. For the normal use however, in this case a static address will have to be assigned.

The program OfficeMaster Gate Configuration (OfficeMasterGateConfig.exe) is used to find OfficeMaster Gate in the network. By clicking the correct button, sub network wide search for OfficeMaster Gate is started via UDP broadcast. Sub network in this case is the physical network, in which the computer with the IP configuration program is integrated. This sub network is usually restricted by network routers, for example firewalls, that do not redirect the UDP broadcast.

In order to assign an address to OfficeMaster Gate, Office Master Software either uses an distinct IP address or the resolved name.

If OfficeMaster Gate, as described above, is used as DHCP client, than it should be ensured, that OfficeMaster Gate is available under the same IP address after reboots, so that the Server-Software can continue working properly.

Possible ways of ensuring this:

At the DHCP server, an IP address is reserved for the MAC address of OfficeMaster Gate. This way, OfficeMaster Gate receives the same IP address after every reboot. In the OfficeMaster Server Software, instead of the IP address, the resolved name is configured. Now when the DHCP server automatically refreshes the DNS server, OfficeMaster Gate will still be reachable by the Server Software, even after having been assigned a

different address.



1.3. Installation of the Survivable Branch Appliance

1.3.1. Rear view of server machine

OfficeMaster SBA is shipped as an Appliance with preinstalled components:

- Industrial grade server machine (e.g. HP ProLiant)
- Main Gateway Board with 4BRI / 2PRI interfaces (can be licensed on demand)
- Separate 4FXS analog interface card (optional)

Separate Y-cables are available if all 4 BRI ports are to be used – the first 2 BRI ports can be utilized using standard ISDN-cables.



Image 1.1: Rear view SBA

1.3.2. Anatomy of the Media Gateway Board (MGB)





The Primary Rate Interface (E1/T1) is implemented in a FPGA (Field Programmable Gate Array), which contains additional support algorithms. It can even be upgraded in the field to implement more features as needed!

1.3.3. Analog Card – 4 Port (FXS)

Four analog ports are contained on a separate low-profile PCI-Express Card connected to the main gateway board using a flat ribbon cable.



Image 1.3: Analog Card

The cable transports audio signals through a TDM bus as well as separate control information. High quality faxing is possible since no VoIP technology is involved between PSTN and FXS ports.

1.3.4. ISDN and Analog Interfaces

Positions of analog and digital interface connectors are shown in this picture (rear view):



Image 1.4: Interfaces of the OfficeMaster SBA

For BRI ports a separate Y-cable must be used if more than two BRI lines are needed.



Note! Never use PRI 2 without PRI 1 – if only one PRI interface is connected always use PRI 1, otherwise clock synchronization will not work!



Table 1.2: Pin assignment

1	Rx+		Tx+
2	Rx-		Tx-
3		Tx+	
4	Tx+	Rx+	
5	Tx-	Rx-	
6		Tx-	
7			Rx+
8			Rx-



Note! If BRI interfaces are used in the US, a separate FCC approved NT1 Network Termination Unit must be installed to connect to OfficeMaster SBA S/T BRI ports. For LAN-connection, please plug in the network cable into the upper interface (LAN1):



Image 1.5: LAN Port to be used

1.4. Recovery

1.4.1. Survivable Branch Appliance

Use of the Recovery USB Stick

The SBA system software can be reset to factory settings at any time by using the USB recovery stick.

Please follow these steps:

- 1. Connect the SBA device to Keyboard, Monitor and Mouse, either physically, using KVM or through tools like HP ILO
- 2. Plug the USB stick into the front USB port
- 3. Power up SBA, it will automatically boot from the USB
- 4. At the end (message: press any key to shutdown computer) press a key
- 5. Remove USB stick
- 6. Power up SBA
- 7. Set the local Administrator password to OfficeMaster!
- 8. Check network interface configuration (see below)



- 9. Open a cmd console and enter the following commands: %systemroot%\system32\inetsrv\appcmd. exe set APPPOOL omsba_admin_pool -processModel.userName:ofmadmin %systemroot%\system32\ inetsrv\appcmd.exe set APPPOOL omsba_admin_pool -processModel.password:Sefte25AuTib
- 10. Now the deployment Web UI is ready for use



Note! When a SBA is shipped, the serial number of the embedded gateway board is already preconfigured. After using the recovery image, the gateway serial number will be queried later by the Web UI during deployment. The serial number of the gateway board can be found on a card, which can be pulled out at the front side:



Image 1.6: SBA serial number

In this example the number to be entered is 259 (last 5 digits without leading zeros). (On some models, the number may be handwritten and may contain the serial number only, without the prefix, e.g. 234).



Check of the network interface configuration

During deployment of the Windows image via USB stick, the desired network configuration is automatically established:



Image 1.7: Network bridge on the SBA

This is the standard configuration, where the gateway board (can be identified as Realtek Controller) is bridged with the LAN port (Local Area Connection 2), which is used for connecting to a switch. The unused second LAN port (Local Area Connection 3) is disabled. In some situations (e.g. due to different BIOS revisions), the physical LAN adapters have different internal id's, meaning that the restored configuration must be corrected manually.



Image 1.8: Example of a network configuration that needs to be corrected

The necessary changes in this case are:

• Right click on Network Bridge – Properties

• Make Local Area Connection 4 (LAN Port) and Local Area Connection 5 (Gateway board) the only members of the bridge

Disable Local Area Connection 6



Now all network configuration settings should be made on the network bridge only. The SBA is ready for deployment after a final reboot.

1.5. Stainless steel box - Restore to factory settings

At the front as well as at the back of the case of the version for BRI's, there is one micro button each:

Table 1.3: Button on the stainless steel box

÷.

Micro button front	Hardware Reset	reboot system
Micro button rear	Software Reset	reset configuration parameters Function is deactivated one minute after booting is completed (signaled by blinking diodes)

Reinstalling the software

Should OfficeMaster Gate (in the stainless steel version with 4 BRI) stop working properly, a recovery can be done with newer versions of the product (February 2011 onwards, distinguishable by the USB port on the side). To do this, the Gateway needs to be disconnected from the power supply and the recovery stick from the bottom of the case has to be plugged into the USB port. Afterwards, reconnect the Gateway to the power supply. Turn off the Gateway after roughly 30mins and remove the stick. When used afterwards, make sure a backup of the configuration is loaded and, if needed, an update of the firmware is made.

1.6. Update and Upgrade

Ferrari electronic constantly releases updates for the OfficeMaster Gate firmware. Check the release notes if the latest version provides any practical changes for your particular IT infrastructure. In order to update the firmware, simply select Firmware update from the OfficeMaster Gate configuration program dialogue.

Leave the settings for automatic update on its default and initiate an update request via internet.

/ 31 7 - 517				
← ≝¶ Offic	ceMaster Firmware Update			
Welcome	•			
Welcome to t your PC. The available; ad	the Firmware Update Wizard. Y update wizard can automatica vanced users can also use the	ou can update the Ily update your d manual update op	e software on your O evice with the latest s ption to update to a s	fficeMaster Gate using software version pecific software version
Update the f	ollwing device:			
Name: IP address:	OMGA00337 10.3.6.10			
Version:	OMG 4.0			
🛕 It is nec	essary to reboot your device t	o install a newer i	firmware version.	
What do you	want the wizard to do?			
Check for	r the latest version on internet			Proxy
O Select fin	mware version manually.			
To continue,	click Next.			
			Ne	ext Cancel

Image 1.9: Firmware update via internet



OfficeMaster Gate initially tries to access the update server; if it fails the configuration programme attempts the same. Please only select firmware version manually if the latter attempt fails again.

Various firmware versions are available to you, such as

- the official release
- the test release preview for the upcoming major release
- the developer release (on request only)
- the release as it was during certification by Microsoft

		?	×
⊢ ≝ Offic	eMaster Firmware Update		
Repository:	Release 💌		
Name omg-modu omg	Release (Release Version der OfficeMaster Gate Firmware (C Develop (Entwicklungsversion der OfficeMaster Gate Firmw Test (Test Version der OfficeMaster Gate Firmware (CentOS Certified (Zertifizierte Version der OfficeMaster Gate Firmware Upgrade (Ugrade to Version 4.1)	CentOS)) vare (CentOS)))) are (CentOS))	
Re-Instal	I packages that are already installed and at the newest version. e newest versions of all system packages currently installed on the syste	m.	

Image 1.10: Selecting the desired firmware version

Upgrade

The 4.1. release offered the opportunity to voluntarily upgrade the version 4.0.xyz to 4.1.xyz.

To do that, choose *upgrade*. The configuration programme will subsequently install the release version of firmware 4.1. If, however, you want to change to a test version, restart the OfficeMaster Gate and select Test.

Downgrade

Downgrading to another version can only be carried out by downloading the respective firmware as .tar file (available on our website) and installing it via the configuration interface.



				?	×
← 📑 Offic	eMaster Firmware Update				
Welcome					
Welcome to t your PC. The available; ad	he Firmware Update Wizard. Y update wizard can automatica vanced users can also use the	ou can update the so Ily update your devic manual update optior	ftware on your OfficeMas e with the latest software n to update to a specific se	ter Gate u version oftware ve	ising ersion.
Update the f	ollwing device:				
Name: IP address: Version:	OMGA00337 10.3.6.10 OMG 4.0				
🚹 It is nec	essary to reboot your device t	o install a newer firm	ware version.		
What do you	want the wizard to do?				
O Check for	r the latest version on internet			Proxy.	
Select fin	mware version manually.				
To continue,	click Next.				
			Next	Can	cel

Image 1.11: Selecting firmware manually

	?	×
🔶 🗄 OfficeMaster Firmware Update		
Select a file		
Choose the software version which will be installed as new firmware		
Firmware file:		_
1		
Next	Ca	ncel

Image 1.12: Selecting the firmware file



2. WORTH KNOWING

Offline configuration Firmware update Licensene management

User manual for administrators | Ferrari electronic AG

Copyright © 2017 Ferrari electronic AG

UNIFIED COMMUNICATIONS www.ferrari-electronic.com



2. Worth knowing

2.1. Offline Configuration

The settings can be configured and then tested without the hardware and ISDN interface being present. This enables, among other things, the following scenarios:

- The creation and testing of a customer configuration which is then transferred by email. The customer loads the .*cfg* file they receive into the gateway.
- Displaying and, if required, correcting a customer configuration
- For training purposes: provides a way for staff to practice using the options for configuring OfficeMaster Card/Gate.

Select File > Offline Mode to toggle the configuration program to this operating mode. Then click *Open...* or select File > Open... to open an existing configuration (.*ofg* file). Alternatively, a new configuration can be created by selecting File > New... and then selecting the hardware variant.

2.2. Logging/Syslog

Programs running in OfficeMaster Gate can send information about the ongoing processes to the Syslog-Server if needed. This is especially helpful when trying to determine the cause of errors. In order to activate this function, Edit > Logging... has to be activated.

📲 Logging					\times
Syslog SNMP CallPro	oc ISDN	Fax T.38	Interconnect	RTP	
 Disabled 					
Via IP-Network					
SysLog Server	10 . 1 .	1 . 🔋			
SysLog Port	514 🜩				
SysLog Protocol	UDP 🔻				
◯ To local file system					

Image 2.1: Syslog Server

In the tab *Syslog*, the IP address of the Syslog Server and the used port (Default: 514) have to be inserted. In the other tabs, detailed settings as to how detailed the logging is supposed to be can be edited. In order to prevent as many errors as possible, the Ferrari electronic Support and other helping instances will set specific settings. Following an error, the logs of the Syslog Server can be forwarded for example as ZIP archive.

If no Syslog Server is available within the network, the program *syslog.exe* can be found in the program folder of the configuration software (Default: C:\Programs\FFUMS\omgatecfg). In the prompt *cmd.exe* the windows service can be installed via the option -install and configured via -config.



2.3. Saving the configuration

The current configuration can be saved to a PC via File > Backup. Vice versa can the saved configuration be loaded into OfficeMaster Gate via File > Restore.



Image 2.2: Saving the OfficeMaster Gate configuration

The following information is not saved:

- Network configuration
- Certificates
- License files

Backups are therefore portable and can be implemented on further gateways.

2.4. Firmware update OfficeMaster Gate

New versions of the firmware running in OfficeMaster Gate are provided frequently in order to implement additional functions as well as bug fixes. Information about the currently available version can be found in the download area of www.officemaster.de as well as in the release notes in the forum. Information about the version used in OfficeMaster Gate can be found in the OfficeMaster Gate configuration (OfficeMasterGateConfig.exe).



Note! The following specifications are based on Office Master Gate. For older OfficeMaster Card/Gate products and the for them needed firmware version 1.xx please refer to the documentation received with the hardware.



After the connection to OfficeMaster Gate has been established, *Firmware-Update* has to be pressed. The update process will start after pressing Start and can take a few minutes. The controller will in the end restart automatically. There are multiple possible scenarios for an update of the firmware.

- 1. Integration of the firmware via the OfficeMaster Gate configuration through manual selection of the firmware package. The current firmware can be found in the download area of www.office-master.de.
- 2. Integration of the firmware through the OfficeMaster Gate configuration by automatically downloading the current firmware via the internet connection of OfficeMaster Gate.
- 3. Integration of the firmware through the OfficeMaster Gate configuration by automatically downloading the current firmware via the internet connection of the administrators computer and automatic transfer through the OfficeMaster Gate configuration to OfficeMaster Gate.
- 4. Integration of the firmware through SSH-Login on OfficeMaster Gate. Execute the command *omgupdate* via the internet connection of OfficeMaster Gate.

Prereleases of the firmware which have not been cleared for distribution can be found on our website under the Test section. These can also be installed.

2.5. Changing Password

The password for logging in to the controller (Standard: "omc") can be changed via File > Change Password.

2.6. License management

OfficeMaster Gate are upgradeable in regards of ISDN ports or functionalities locally via extension licenses. The activation of additional functions takes place in two steps:

- The by the customer purchased extension license, which possesses its own serial number, has to be registered with Ferrari electronic first.
- Based on the registration the customer will receive a fresh extension license which is tailored specifically to the serial number of the customers OfficeMaster Gate. The extension license can only be used for this specific OfficeMaster Gate.

The configuration program supports the registration and activation of extension licenses. The configuration program has to be connected to the OfficeMaster Gate on which the extension license is to be used. The license management can be accessed via Edit > Manage licenses....

2.6.1. General settings

► License State

License State displays which ports and functions are activated for the with the configuration program connected OfficeMaster Gate.

Supported Interfaces

Here, the maximum number of interfaces is displayed. This is unrelated to the number of integrated licenses.



The actually licensed interfaces are listed below and depend on the hardware as well as the integrated licenses.

📲 Manage Licenses	×
Common Advanced	
License State	
Supported interfaces:	2
Licensed PCM interfaces	2
Supported B channels:	60
Licensed for Lync / EX2013	60
Licensed for Unified Messaging	2
Licensed for SIP2SIP	2
Other Features	
Licensed SIP2Lync Users	0
Licensed EntryControl Terminals	0
OfficeMaster Directory Service	0
Product Activation	
To add an additional license or any more OfficeMaster have to activate your product and start a license requ to Ferrari electronic via internet connection or e-mail.	Gate PCIe Board you Jest. Submit this request
	Activate
Install Licenses	
Ferrari electronic will generate a license file, which is b The license file will be sent to given e-mail address.	ound to your hardware.
	Install
	Close

Image 2.3: License management - Overview

Request new License

Create... opens a dialog for the integration and registration of or more extension licenses. *Add* includes one or more extension license files into the list. A file selected in the list can be deleted, edited or replaced.

The registration information can be submitted either via email or via the internet. *Next* opens additional dialogs for entering customer and personal data, which are needed for the registration.



Note! The information regarding company and contact person (Last name and email address) are essentially required for the distribution of the activation license.

The first step of installing the extension license is completed once the registration information has been send. Based on the information gives in the registration Ferrari electronic will distribute a license file for each registered extension license. This license file has to be implemented into OfficeMaster Gate via the configuration program. The name of the license file is combined out of the original name of the extension license and the serial number of the to be extended OfficeMaster Gate.



Example 2.1.

Serial number of the extension license:

99-EOMGB00010.fle

Serial number of OfficeMaster Gate:

OMG200123

Name of the distributed extension license:

99-EOMGb00010_OMG200123.fle

»End of example

Install Additional License

Install... in the dialog window opens a file selection dialog, which enables the selection of the modified extension license. The selected license is then imported. Here it will also be checked if the configuration program is connected to the OfficeMaster Gate for which the license was created. A message will inform about the successful import. Otherwise an error report will be shown.

Following a successful import the license management can be closed by clicking on *Close*.



Note! Only after a reboot of OfficeMaster Gate will the license information become active.

2.6.2. Advanced settings

The tab *Advanced* displays already imported extension licenses. An already imported extension license can be deleted by selecting it and clicking *Remove selected*. *Export*... enables the export of the license files onto another medium.

📲 Manage Licenses	\times
Common Advanced	
Uninstall Licenses	
License files	
140-OMGV00447.flf	
Export Remove selected	

Image 2.4: managing existing licenses



3. CONFIGURATION

Basics Media Gateway configuration Drop & Insert

User manual for administrators | Ferrari electronic AG

Copyright © 2017 Ferrari electronic AG

UNIFIED COMMUNICATIONS www.ferrari-electronic.com



3. Configuration

The products of the OfficeMaster Gate family use a coherent firmware as a base, which operates the depending on hardware available ports

Because of the coherent base and the therefore identical configuration-ports, every OfficeMaster Gate of the 3rd generation can be operated with the same user interface.

Even though the essential configurations of OfficeMaster Gate are identical, when installing the SBA and the Hybrid Gate, additional steps of configuration are necessary.

3.1. OfficeMaster Gate Basic Settings

If OfficeMaster Gate is used solely in combination with the Unified Messaging Software OfficeMaster, then the configuration is made via the integrated administration program (see manual for OfficeMaster Administration). The gateway function of OfficeMaster Gate can be enabled if needed.

For the activation and configuration of the gateway function, an administration program (*OmGateConfig.exe*, installed via *SetupOfficeMasterGateConfig.exe*) is provided, which can be installed at any work space. A mixed use as gateway and Unified Messaging Controller for OfficeMaster can be set up with this program. The main dialog will pop up after starting the configuration program:

۲ę	OfficeN	laster G	ate Configuration - 6.1.	3.1102 (10.0.0.185)	—		×
File	Edit	View	Tools Help				
	N	r	Common				
			Туре	OfficeMaster Virtual Gate			
			Name	VGateAndy1 (s/n: OMGV004	47)		
t	Conn	ect	B-Channels	60			
•	🔎 Search		UserFS Version	OMG 4.0	Firmw	are Updat	e
			Network Settings				
			Mode	Client			
			IP Address	10.0.0.185			
			Subnet Mask	255.248.0.0	-1		
			Default Gateway	10.1.0.10	Change	e IP Addre	SS
			OfficeMaster Gate				
			Operation Mode	Gateway/mixed			
			Configuration Mode	Advanced	Chan	ge Setting	s

Image 3.1: Connected OfficeMaster Gate

Some of the elements will only become active once a connection to the controller is provided (see next section).



Note! The language can be toggled between German and English in the help menu.



3.1.1. Connecting to OfficeMaster Gate

After the start of OfficeMaster Gate configuration, the connection to OfficeMaster Gate has to be established. Via File > Search or by pressing the search symbol, name, IP address, version and number of channels of the found controllers are listed:

Name	Version	IP Address	в	^
VGateSip2Lync (s/n: 00060)	4.0	10.6.1.28	60	
VGateOMDS (s/n: 90466)	4.0	10.0.0.86	60	
VGateMarko1 (s/n: 00867)	4.0	10.0.0.126	60	
🗢 VGateJulian1 (s/n: 08277)	4.1	10.4.50.162	60	
✓ VGateJohannes2 (s/n: 904	4.0	10.0.0.84	60	
🗢 VGateCentral (s/n: 07017)	4.0	10.1.1.33	60	
💚 VGateBert1 (s/n: 00470)	4.0	10.0.0.111	60	

Image 3.2: Available OfficeMaster Gate in the Network

In this list, the preferred entry is selected and confirmed by pressing OK. This login dialog will then appear:

Login Request		E.	
OfficeMa	ster ™	ele	ectronic
IP Address: 10 Password:).0.126	~	
		Ok	Cancel

Image 3.3: OfficeMaster Gate login

This dialog can also be accessed directly via File > Connect, in order to enter the IP address of OfficeMaster Gate manually. For authentication purposes, a password is required.



3.1.2. Network configuration

In order to change the network settings (for example IP address) the button *change IP address...* has to be pressed. Alternatively the same can be achieved via Edit > change IP address. Depending on the structure of the used network, IPv4 and/or IPv6 addresses can be declared.



Settings	×	Network Settings ×
General IPv6 Proxy	Gene	eral IPv6 Proxy
Name: OMG800328	Mod	de: Automatically
Serial Number: OMG800328 Mode: DHCP Client	Use IPv	Automatically the following IPv6 address:
Use the following IP address:	Sub	bnet prefix length:
IP address: 10 , 0 , 0 , Subnet mask: 255 , 248 , 0 ,	177 Det	fault gateway:
Default gateway: 10 , 1 , 0 ,	10 Pre	eferred DNS server:
Use the following DNS server addresses:	Alte	ernate DNS server:
Preferred DNS server: 10 , 1 , 1 ,	1 Sea	arch Domain:
Alternate DNS server: 10 , 1 , 1 ,	2	´
Search Domain:		
C	K Cancel	OK Cancel

Image 3.4: Network settings



Note! The configuration program communicates through UDP-Broadcasts via the port 3216. With OfficeMaster this also works through interposed switches, while routers usually will not forward the Broadcast-Messages.

The mode activated on shipment of OfficeMaster Gate is DHCP-Client. Possible modes of operation are *DHCP-Server (IPv4 only)*, *DHCP-Client* and *static*.

► DHCP-Server (IPv4)

The DHCP-Server mode is only useful for OfficeMaster Gate, if OfficeMaster Gate is connected to a host computers network card via cross cable and when this network card is run in DHCP-Client mode.

► DHCP-Client (IPv4)

This is the standard setting of OfficeMaster Gate. In this mode of operation it is assumed that there is a DH-CP-Server existent in the network, which will assign the controller with an IP address and every other required value. OfficeMaster Gate registers itself under the name that is shown in the first slot of the IP configuration program. If the DHCP-Server automatically initiates a DNS refresh then OfficeMaster Gate can be contacted directly under that name in the network.

► Static (IPv4)

Is the network run without a DHCP-Server then OfficeMaster Gate needs to get a static IP address, a subnetwork mask, a gateway address (optional) as well as the address(es) of the DNS Server(s) assigned to it.



A Domain Server Name (DNS) has to be assigned, when the target systems are addressed via FQDN (Fully Qualified Domain Name). Because these can, on occasion, malfunction, a alternative DNS should be configured as DNS2.

► Automatically

With this setting, an automatically assigned IPv6 address will be used.

► Static IPv6 Address

Similar to IPv4, with IPv6 as well the declaring of a static IP address is possible. Are the target systems contacted via FQDN (Fully Qualified Domain Name), at least one Domain Name Server (DNS) has to be declared. Since one DNS server can fail at any time, an additional one should be configured as DNS2.

► Proxy

Should a connection in the network be restricted to a Proxy only, it can be configured in the tab *Proxy*.

3.1.3. "Common"

📑 Advanced Config	juration			×
PCM 1 PCM 2				
Common Calls fro	m ISDN Calls to ISDN M	essage Waiting		
Number of Channels t	o Use			
Outbound	30 ≑			of Total 30 韋
Inbound	30 🜩			
ISDN Connection				
Туре	Point-to-Point (DID)		QSIG 🗹	Onboard Termination
	Point-to-Multipoint (MSN)			
ISDN Type of Number,	Mapping from/to E. 164			
Type of number	from ISDN	to ISDN		
International				
National				
Subscriber				
Apply to	Called Party Number	Called Party Number		
	Calling Party Number	Calling Party Number		
	Redirecting Number	Redirecting Number		
Add. Parameters				
More >>				OK Cancel

Image 3.5: ISDN Settings



Number of Channels to use

In the following it is decided, whether the existing B-Channels are to be used completely for in-and outgoing connections or if, for example outgoing calls are only allowed to use a certain percentage, so that there are free channels for incoming calls under any given circumstances.

Outbound

Defines the maximum amount of channels that will be used for outgoing calls.

Inbound

Defines the minimum amount of channels that will be used for outgoing calls.

of Total

Total of B-channels used.

▶ [...]

By pressing [...], a dialog will open up, enabling the user to define the maximum amount of B-Channels, for example with "halved" PRI ports. This "incomplete" pin assignment is relatively common outside of Germany.

ISDN Connection

The different types of connection are Point-to-Multi point and Point-to-Point.

► Point-to-Point (DID)

Point-to-Point only supports one ISDN device, usually a telephone system or a media gateway. A Point-to-Point connection assigns a complete dial through numbers area.

► Point-to-Multi point (MSN)

Point-to-Multi point connection only supports a limited number of recipient call numbers (usually 3 to 10), so called MSN (Multiple Subscriber Number). Here, multiple ISDN devices (Phone 1, Phone 2, Fax) can be connected.

► QSIG

Additional to Euro-ISDN or DSS1, there is also QSIG. This is an ISDN protocol that is sometimes used by a selective number of telephone systems. Via QSIG, additional information like the callers name can be transmitted.

Onboard Termination

OfficeMaster Gate for BRI allows the addition of ISDN terminating resistors, which should usually be existent in the ISDN socket. By default, these internal terminating resistors are deactivated.



A LED can be found on the left side below the ISDN socket of OfficeMaster Gate (stainless steel edition). If this one is lit, then the firmware enabled the terminating resistors according the configuration settings.



Note! Usage without terminating resistors can lead to ISDN errors. In older versions of the hardware, this LED will be triggered if the terminating resistors are off! The settings in the configuration program are in effect in any way.

► NT Mode (Network Termination)

This option is usually used in order to place the gateway between the telephone network and the PBX. Towards the telephone network the gateway acts like a PBX (as TE, meaning Terminal Equipment), while towards the PBX it acts similar to the trunk.



Note! This only works in Point-to-Point mode. Common terminals will not be usable on this line as such devices usually run in Point-to-Multi point mode. Additionally, a cross cable needs to be used for the connection with the PBX.

▶ [...] – Advanced Connection Parameter

Dial Timeout

When simulating an external line, numbers of any random length will be communicated by the telephone system. In order to decide which calls are supposed to be redirected outward, a timeout is set, after which no more digits are to be expected. This timeout usually happens after 3-5 seconds.

► Caller Name Display Mode

Is QSIG activated in the ISDN protocol, caller names can be transmitted for incoming and outgoing calls. Since this is based on different protocol versions depending on the system, testing is the only way to find the right setting.

▶ No L2 auto-activation (Point-to-Point Options)

With a Point-to-Point connection, the gateway will try to keep active the layers 1 and 2 in the D-Channel at all times. This behavior can be deactivated here.

▶ ISDN Type of Number, Mapping from/to E.164

Type of Number is usually defined in ISDN in order to define information about the type of call. Internally (for example Lync or OfficeMaster Suite) calls are usually in E.164 format, meaning that they need to be adjusted properly.

International

With calls from ISDN, the configured *call number* (for example "+") is fronted when the *Type of Number* (TON) is set to *international*.

For outbound calls, meaning to ISDN, the TON is recognized via the configured call number and the call number removed.



National

National numbers are treated equivalently to international numbers.

► Subscriber

The local connection is entered under *Subscriber*.

Apply to

Insert here, for which numbers the adaptations are to be made.

Example 3.1.

Creating an E.164 number from TON for inbound calls

ISDN Type of Number, Mapping from/to E, 164				
10014 Type of Number	, happing nonyto Erron			
Type of number	from ISDN	to ISDN		
International	+	+		
<u>N</u> ational	+49	+49		
Subscriber	+4930	+4930		
Apply to	Called Party Number Calling Party Number Redirecting Number	Called Party NumberCalling Party NumberRedirecting Number		

Image 3.6: Example for an automatic creation of an E.164 number

Table 3.1: Submitted information on inbound call

Called Party Number	National 89123	+493055948
Calling Party Number	Subscriber 55948	+4989123

With settings as seen in Image 3.6, the inbound signal from Table 3.1 is converted into an E.164 number. Afterwards, OfficeMaster Gate's set of rules are applied for further customization of the phone numbers and for the delivery towards the appropriate destination as described in the following paragraph (3.1.4).

»End of example



Example 3.2. Generating the ISDN information for outbound calls

For outbound calls the process is inverted. The settings of the sector *ISDN* apply.

Table 3.2: Conversion of E.164 to ISDN

Called Party Number	National 89123	+493055948
Calling Party Number	Subscriber 55948	+4989123

»End of example



Note! More complex setting for TON are available via the creation of single rules for inbound, respectively outbound rules.

► More – Settings for multiple channels

OfficeMaster Gate is available in versions with multiple ISDN channels. The configuration program supports this by letting the user configure channels individually. Alternatively, all channels can be defined to copy the settings of the first channel. This can be activated via the button *More>>* in the configuration dialog. Here the user defines which channels are to be used. Pressing *More<<* again hides the area. Has the individual configuration of the channels been selected, the upper area of the dialog will display the channels that are available for configuration.

3.1.4. Calls from ISDN

For the selection of the target gateway, a separate tab is available in the advanced mode. In this tab, targets are chosen depending on the calling number and reshaping can be done.

In the tab Calls from ISDN a list of the configured rules is shown:

ommon Calls from ISDN Cal	ls to ISDN Message Waiting	a	
🚰 Add 🛛 🚰 Edit 🛛 🗙 Remove		† +	🙉 Test.
Name	Rule	Substitution	Destination
Kopfnummer wegnehmen	455(); (.*), (.*), (.*),(\1,\2,\3,\4	
Callmanager Postfach	(250),(.*),(.*),(.*)	\1,\2,\3,\4	V





In this dialog you can add, delete, process and change the sequence of these rules. To edit, delete or move a rule, click on it with the mouse button to select it and then select the action you require.

Additional options are offered by the context menu, which is opened by right clicking an entry:



Image 3.8: Context menu for Gateway rules

Many of these functions can be used with multiple rules at the same time. For this, the rules need to be selected via multi-marking (Shift resp. Ctrl + left mouse button).

For when a new rule is created, the fields are set up to select any number and to remain unchanged after substitution (substitution by itself.)



Usually, at least the pattern for the *Calling Party Number* will have to be edited in order to suit the extension number length or specific MSNs. The rule should be given a descriptive name. For every rule, a type (e.g. *Routing, Replacement, Blocking*) and for rerouting rules, a target will need to be configured.

Fx	General	
~	Display Name	New Rule
	Туре	Routing -
	Match and Replace	
	Pre-Check Number List	<not specified=""> ~</not>
		Treat as negative lookup list
	То	Match (.*) Replace \1
	From	Match (.*) Replace \2
	P-Asserted-Id (PAI)	Match (.*) Replace \3
	Diversion	Match (.*) Replace \4
	Fax Detection	
	Detection timeout	15 🔹 seconds Fax Routing
	Fax CSID	▶
	Destination	
	Mode	SIP Multiple Destinations
	Host	
	Protocol	TCP Port 5060
	Add. Parameters	
	Parameter Profile	<use global="" settings=""></use>

Image 3.9: Creating a new rule for inbound calls

Possible settings regarding rules for incoming calls

► General

Display Name

Here, the rule should be given a descriptive name.

► Type

Defines the type of rule.

- Routing Defines a target, to which the call is redirected should this rule become active. Other rules below this one are then disregarded.
- Replacement Manipulates the phone number by, for example, adding or cutting digits to or from the number. After that, the next rules are processed.
- Blocking The processing of the call is ended should this rule become active. Most useful for outgoing calls, in order to direct those to specific ISDN ports and block them from others.



► Match and Replace

▶ Pre-Check Number List

A separately licensed software can enable the gateway to provide number lists, which the rules can call upon. With this, complex dial plans which have no clear pattern to the numbers involved, can be realized. Additionally, the separate software Lync phone numbers can be regularly replicated from the AD into the gateway, so that it can be decided automatically whether incoming calls are meant for the telephone system of for the Lync server.

► Match/Replace

In the match fields, patterns for comparison are given in form of regular expressions. These are compared with the existing values and information is saved in brackets. Afterwards the replace field is processed, in which information is referenced and if needed completed by additional characters. Detailed information for this and for the fields *Called Party Number*, *Calling Party Number*, *Calling Party Number*, *2* and *Redirected Number* can be found under Basics of telephone numbers.

► Fax Detection

The following settings only come into effect once this check box is activated.

Detection Timeout

Is this box checked then the incoming audio signal at the start of the connection is, for the duration of the set Detection Timeout, scanned for CNG tones. Depending on the settings in the VoIP parameters, either CNG events are redirected in the RTP protocol or a reINVITE for a T.38 connection is issued. T.38 is used in combination with Exchange 2007 for incoming fax messages. With Exchange 2010 UM, OfficeMaster Gate can directly receive fax messages, without having to use T.38 (see Receiving Fax with Microsoft Exchange 2010).

► Fax Routing

Via this option, an Exchange fax receive can be realized in Lync resp. OCS environments without a separate dial through number. Unfortunately, the recognition of a fax connection only works after picking up the call. In this case, the user would pick up the call, which would be ended a few seconds late again if it is a fax call. This call would then be redirected to Exchange. Due to this restriction, this function is rarely used.

Receiving fax in Exchange 2007 always requires a connection to the voice box of the user. After that, the gateway needs to recognize that a fax is to be received and then inform the Exchange server.

Should no receiving of fax messages be wanted this way (f. Ex. because separate dial through numbers exist for fax), the recognition of fax calls can be deactivated as well. For this, the check box *Fax Detection* has to be deactivated.

If Fax Detection is activated, then it is only trying to do so for a limited time, as otherwise longer connections to the voice mailbox could lead to sound signals falsely triggering the switch to fax mode.



Caution! When Lync or OCS 2007 (for telephony) and Exchange 2007 (for voice mail) are used together, the switch to fax will not work, as Lync and OCS contact the Voice mailbox themselves and don't support fax.



In order to enable fax none the less, without having to set separate fax dial through numbers, OfficeMaster is able to switch to an alternate target (Exchange or OfficeMaster), should a fax connection be recognized. For this, the check box *Fax Routing* has to be activated in the according rule (which usually routes to Lync resp. OCS).

In the following dialog, the target responsible for receiving fax messages is configured. The configuration is comparable to other rules for incoming calls.

► Fax CSID

Here, a separate fax ID can be declared, in which by referencing to the Called Party Number, the user dial through number could be displayed individually.

Destination

Multiple destinations are possible destinations for incoming calls.

► Mode

The mode for a connection to Exchange UM or Lync/Office Communication Server should be SIP. Shall a call (fax, SMS, voice mail) be handled by the OfficeMaster Messaging Server, OfficeMaster has to be chosen. Further modes are *ISDN* (for when a call shall be directed via ISDN once again) as well as *REGISTERED* (the call is redirected to a SIP installation, as long as that installation is registered under the number accompanied by the call).

► Host

For SIP mode you must specify the target computer either by entering its IP address or a fully qualified host name.

Protocol

The protocol used for the targets described here is either TCP or TLS. UDP is for example often used in combination with analog adapters.

► Port

Typical values for the target port: *Exchange/TCP 5060*, *Exchange/TLS 5061*, *Lync/TCP 5068* and *Lync/TLS 5067*. With Lync Servers, the actual value can be seen in the Topology Builder in the section Mediation Pool.

Add. Parameters

This is where you edit additional settings. This box usually remains empty. You should only use it if told so by the Ferrari electronic hotline.



► Multiple Destinations

In SIP mode you can specify more than one target so that, for example, if a computer crashes, any inbound calls can be forwarded to another computer. If you click the *Multiple Destinations* check box, the dialog changes.

In OfficeMaster mode, additional priorities can be set. Destinations with equal priority trigger an automatic divide onto those destinations.

A	General				
	Display Name	OCS Inbound Rule			
	Туре	Routing -			
	Match and Replace				
	Pre-Check Number List	<not specified=""> ~</not>			
		Treat as negative lookup list			
	То	Match (7) Replace +493328455\1			
	From	Match (.*) Replace \2			
	P-Asserted-Id (PAI)	Match (.*) Replace \3			
	Diversion	Match (.*) Replace \4			
	Fax Detection				
	Detection timeout	15 🔹 seconds 🛛 Fax Routing			
	Fax CSID	•			
Г	Destination				
	Mode	SIP Multiple Destinations			
	Host	lync.hq.ferrari-electronic.de			
	Protocol	TLS Port 5067			
	Add. Parameters				
	Parameter Profile	<use global="" settings=""></use>			

Image 3.10: Destination for calls in the rule section


3.1.5. Calls to ISDN

Aside from the manipulation of incoming calls, the manipulation of outgoing connections is also possible. With this, for example an automatic trunk seizure can be set up.

Example 3.3.

In the tab *Calls to ISDN*, a list of outbound rules is shown. Rules can be added, edited or deleted. Different to incoming calls, outbound calls are checked for a match with all active ports. Has a matching rule been found, the call is send on the port, that this rule was assigned to. If multiple matches occur, the ports are used interchangeably, as long as there is an open B-channel.

Advanced Configuration			? ×
PRI 1 PRI 2 PCM 1 PCM 2			
Common Calls from ISDN Calls to	ISDN Message Waiting		
🛅 Add 🛛 😭 Edit 🛛 🗙 Remove		↑ ↓	🙈 Test
Name	Rule	Substitution	Destination
Block	(7),(.*),.*,(.*)	\1,\2,\3,\3	ISDN
Null für Zentrale dazubasteln Bert wars	(455959),(*),.*,(.*)	\1,0\2,\3,\3	
Redirected Calls	(.*),(.*),.*,(\+.*)	\1,\3,\3,	
CGN	(.*),\+493328455(.*),	\1,\2,\3,\3	
Umgeleitete Rufe (noch ein plus vorha	(.*),\+(.*),.*,(.*)	\1,90,\3,\3	
CCM Nummer anzeigen	(.*),7(40 41 44 45 47	\1,9\2,\3,\3	•
Ferrari 8818	\+493328455(8.*),(.*)	\1,\2,\3,\3	ISDN
Ferrari CCM	\+493328455(),(.*),	455\1,\2,\3,\3	ISDN

Image 3.11: Set of rules for outbound routing

»End of example



Example 3.4.

The picture below shows a rule, which recognizes German phone numbers in the E.164 format (plus-sign, country code, area code without initial 0, participant number) and converts them into dialable numbers. The character sequence +49 is replaced by two zeros, one for the trunk seizure and one for the area code. +49332845590 is converted into 00332845590.

📑 Call Pi	rocessing		×
Properti	es		
	General		-
<u></u>	Display Name	CPN National	
	Туре	Routing -	
	Match and Replace		- 1
	Pre-Check Number List	<not specified=""></not>	
		Treat as negative lookup list	
	IP Address	~	
	Called Party Number	Match \+49(.*) Replace 00\1	
	Calling Party Number	Match (.*) Replace \2	
	Redirecting Number	Match (.*) Replace \3	
	B		
	Image	3.12: Rule for an outbound call	

»End of example

3.1.6. Testing routing rules

The functionality of the configured rules can be tested directly in the configuration program, even without an existing ISDN connection. For this, press the *Test* button on the right side above the rules.

📲 Advanced Configuration			? ×	Test (*to ISDN*)
				😪 👷 Test Cases 🔻 🛞 Start
PRI PRIZ PONT PONZ				Called Party
Common Calls from ISDN Calls to I:	SDN Message Waiting			Calling Party 1
🛅 Add 🛛 😭 Edit 🛛 🗙 Remove	[↑ ↓	🔗 Test	Calling Party 2
Name	Rule	Substitution	Destination	Pudirected
Block ((7),(.*),.*,(.*)	\1,\2,\3,\3	ISDN	wame
Null für Zentrale dazubasteln Bert wars ((455959),(*),.*,(.*)	\1,0\2,\3,\3		
Redirected Calls ((.*),(.*),.*,(\+.*)	\1,\3,\3,		
CGN ((.*).1+493328455(.*)	11.12.13.13	J	

Image 3.13: Testing routing rules

This will open a test window, in which different values can be tested.





Note! Switching between incoming and outgoing rules is possible, the test dialog will automatically adjust itself. Additionally, rules can be adjusted or added while the test dialog is open. All values entered are kept.

Test (*to ISDN*)
숧 🕂 Test Cases 🔻 😤 🔞 Start
Called Party +493098765
Calling Party 1
Calling Party 2
Redirected
Name
C PRI 1
Block DECT
🗇 strip E. 164
- Calls
🗢 Ferrari
🖻 🔁 National
Called Party = 03098765 Calling Party = Redirected = Destination = ISDN
BRI 1
🗢 strip E. 164
Calls
🗄 🤆 National
Called Party = 03098765 Calling Party =
Close

Image 3.14: Analyzing test results

► Called Party

For testing, a phone number is entered in *Called Party*, all other fields are optional. After starting, the rules are checked for matches. In the result it can be observed, for which rules a match was found and what their effect was.



Note! In the example above it can be seen, that the test for outbound rules was held over all ports and that multiple ways can be found.



3.2. Configuration and Activation of OfficeMaster SBA

This chapter describes the necessary steps to install OfficeMaster SBA. Some prerequisites have to be made in the central data center -the technician in the branch office only needs limited administrative rights to make the necessary steps.



Note! The SBA can be reset to factory settings at any time via the use of the USB recovery stick. Details on this can be found near the end of this document.

3.2.1. Preparations in the central computing center

Before OfficeMaster SBA can be used, a few preparations have to be made in the central data center. Please mind the applicable instructions by Microsoft regarding the Lync Server Software. The necessary steps include setting up a computer account for the SBA and adding a serverPrincipalName via the ADSI Edit for this account. Furthermore, a user account for the SBA administrator of the domain group RTCUniversalS-BATechnicians has to be added.



Note! This membership has to be configured directly via the explained groups and not indirectly via additional groups!

Additionally, a site has to be declared in the Topology-Builder (if not already existent) and in that site, the Survivable Branch Appliance including Gateway has to be defined. The Gateway in the SBA receives its own IP address respectively the fitting DNS entry. Lastly, the topology has to be published. Here, the SBA computer accounts automatically receive the necessary rights.



3.2.2. Installation OfficeMaster SBA

Connect to the web-based administration of the appliance -addressing via the address noted on the provided label. Is there no DHCP server in the network, the appliance will automatically assume the IP address 192.168.101.101 and the network mask 255.255.255.0

Ferrari electronic AKTIENCESELLSCHAFT OfficeMaster SBA Administration Survivable Branch Appliance for Microsoft® Lync™ Server 2013	
Username Administrator Password Login	4745 26265

Image 3.15: First Login

Enter Administrator as Username and OfficeMaster! as Password (will be changed in a later step).



The first dialog after the log-in leads to the network configuration. By selecting *Done*, the DHCP settings will be saved and applied. Alternatively, a static IP address can be entered.

	Ferrari electronic aktiengesellschaft	Survivable Branch Appliance for	A Administr r Microsoft® Lync™ Server	ation 2013
	Bootstrap			
	Network Password Date/Time Domain	Avaliable NIC:	MAC Bridge Miniport	•
F	Install	DNS-Name DHCP	WIN-9M083D3HP7L	
	Activate Gateway	IP-Address / Subnetmask Gateway	10.6.1.6	255.248.0.0
	PSTN Test	DNS-Domain	hq.ferrari-electronic.de	
	Diagnostics Status	MAC Address	02:50:C2:20:AA:50	
		Apply Changes Done		
	_		Logged in as: 4	Administrator Version:2.0.4745.26266

Image 3.16: Initial Network configuration

Select *Apply Changes*, restart the browser and connect via the new IP address.

The following dialog allows the admin to change the password. By selecting *Change Password*, the process is finished.

Administrator Login Name:	Administrator
Old Password:	•••••
New Password:	•••••
Retype Password:	•••••
Change Password	
Done	

Image 3.17: Setting the password of the Administrator



By selecting *Done*, the dialog moves on to the time and date configuration.

Date:	18.01.2013	15	Time:	(10:46 🛊 🕓
Timezone:	(UTC+01:00) A	msterdar	n, Berlin, B	ern, Rome, S	tockholı 🔻
					Refresh
Apply Changes					
Done					

Image 3.18: Time and date configuration

By selecting *Apply Changes*, all changes are applied and by pressing *Done*, the dialog moves on to the next step.

Here, enter a computer name and join the desired domain. After a few moments, the *Reboot* button will become active. The appliance now has to be rebooted and a log-in with the local admin is required.

Local computer settings		
Current Computername	WIN-9M083D3HP7L	
New Computername:	w15rtmd 120	
Domain ioin settings		
Current Workgroup	WORKGROUP	
Current Role	Standalone Server	
New Domain	lync2013.lan	
Domain Account	lync2013\sbauser	
Password	••••	Apply Changes
Local administration gro	up	
Add domain group to local	Administration Group: RTCUnive	rsalSBATechnicians
Done		

Image 3.19: Adding the SBA to the local domain



After the reboot, the predefined domain group *RTCUniversalSBATechnicians* will automatically be added to the local admins. Leaving the dialog by pressing *Done* results in *Bootstrap* being terminated and the installation part being started.

Finish RTC SQL Installation		Time	Message
Install Lync SOL Instance		01:14:02:033	MainEngineThread is retu
install Eyne Ode Installee		01:14:02:033	Decrementing counter to
Install Lync Core Components	V 🖻	01:14:02:033	Custom Action Manager t
Install Lync Server	VP	01:14:02:033	Destroying RemoteAPI of
	•	01:14:02:017	Restoring environment va
Install Mediation Server	< P	01:14:02:017	Decrementing counter to
lease Reboot Computer to ensur	e	01:14:02:017	Note: 1: 1402 2: HKEY_L
installation finalization before		01:14:02:017	Note: 1: 1402 2: HKEY_L
continuing with SBA Activation		01:14:02:017	Incrementing counter to
Reboot		01:14:02:017	Machine policy value 'Dis
		01:14:02:017	User policy value 'Disable '
		4	•

Image 3.20: Overview of the installation progress

The installation will run nearly by itself and is concluded with a reboot. The installation log files can be loaded after every finished step -which can be very helpful in case of any errors.



Note! For the next login, the for the SBA activation prepared account will have to be used. Under this user, the activation of the Microsoft SBA component is executed.

Check Connection to Server	Find Central Management Store
Create local Databases	Create Databases
Download Configuration from Server	Download Configuration
Install Configuration to SBA	Install Configuration
Start Server - SBA Replication Process	Start Replica Process
Activate SBA in Topology	Activate SBA
Done	

Image 3.21: Checking Connection



- Find Central Management Store -makes sure, that a connection to the data base is available
- Create Databases -is only used with Lync 2013 SBA
- Download Configuration -loads the configuration data from the central Management Store
- Install Configuration applies the information and saves it in the local Store
- Start Replica Process enables the continuous replication of changes

After successful execution of the previous steps, the SBA can be activated and the next dialog can be started by pressing *Done*.



Note! If a certificate server exists within the Active Directory, than that server can be used to acquire and install the required certificate. Alternatively, a *certificate sign request* can be generated.

Requesting a certificate online via AD-CA and assigning it

- Enter Username and Password on the left side
- Press Auto-Install Certificate as soon as the certificate is assigned and locally installed, the Thumbprint
 appears
- Press Assign Certificate
 - ▶ Offline Certificate Installation
- Press Offline Certificate Installation -> a separate dialog appears
- Follow the instructions in the dialog window
- Press Done

Automatic from Doma Certificate	Certificate-Request and Installation hin CA (recommended) Authority	Create a Certificate-Request, submit to a CA and install Certificate manually
W15RTMD	C.lync2013.lan\lync2013-V	
Account	bauser	Offline Certificate Installation
Password		
Aut	o-Install Certificate	
Aut ssign newl	o-Install Certificate	
Aut ssign newl	o-Install Certificate y installed Certificate to SBA 32DA6660363E7B4E31917A57D2114522145	Assign Certificate
Aut Issign newl	o-Install Certificate y installed Certificate to SBA 32DA6660363E7B4E31917A57D2114522149 Request Certificates executed	Assign Certificate

Image 3.22: Requesting certificate



Done finishes the section.



Image 3.23: Start of the SBA Services

All local services can now be started by pressing Start Services.



Note! The provided security template can optionally be applied at this point in order to disable undesired services and ports. This should only be done in case of very high system requirements as useful functions like Remote-Desktop will be disabled. Additionally this process will take a long time and can also lead to timeout errors – pressing *Done* right after the start will cause the process to continue in the background. It is advised not to take this step.

Selecting *Done* concludes the activation.

3.2.3. Media Gateway Configuration

The concluding step is the configuration of the Gateway. Most of the time, the Gateway is configured via a separate configuration tool which can be downloaded by pressing the *Gateway* button on the left hand side. A description of this particular configuration step can be found in the chapters OfficeMaster Gate and Lync 2010 and OfficeMaster Gate Configuration.

Media Gateway Board Basic Configuration

The basic configuration of the in-build Gateway card can be made directly via the web interface (The Gateway is a network device and therefore needs its own IP settings).



By pressing *Save*, all the settings are saved and applied. Pressing *Restart Gateway* activates the changes. The Gateway will need roughly one minute to reboot.

Serial Number:	259 Change
ISDN PRI Interface Type:	E1 •
Number of PRI interfaces used:	0 0 1 2
Number of BRI interfaces used:	• 0 • 1 • 2 • 3 • 4
Use the following IP address:	
DHCP Mode:	Static IP address 🔹
IP address:	10.6.1.8
Subnet mask:	255.248.0.0
Default gateway:	10.1.0.10
Use the following DNS server addresses:	
Preferred DNS server:	10.6.1.1
Alternative DNS server:	
Save Restart Gateway	Get OmEnvironmentVariable result:

Image 3.24: Network configuration of the Media Gateway Board

In the next dialog, a simple dial plan can be entered. The Gateway will usually only receive the direct dial through (number of digits is important), therefore the number will have to be completed into a E.164 number by adding the "*local prefix*". Are only BRI Interfaces with MSN (multiple subscriber numbers) in use, then the length has to be set to 0.

Additionally it is necessary that the number code is set and also that the certificate is requested, should it be planned to use TLS and SRTP for VoIP communication.

Incoming Exte	nsion Length	3	•
Local E.164 Pro	efix (e.g. +1234567)	+12626	66
Country Code ((e.g. 1 for USA)	1	
Use TLS			Request Certificate
Phone Numbe	ers for analog FXS Ports	(E.164 Forma	t):
Port #1	+12626663454		Browse
Port #2			
Port #3			
Port #4			
Please configur manipulation u	re Translation Rules in Trunk se separate "OfficeMaster G	Configuration Gate Configurat	- for advanced number ion Tool" which can be
downloaded he	Set BaseDialPlan res OK	ult:	^

Image 3.25: Basic ISDN Configuration



Based on these rules, a few rules for incoming and outgoing calls are automatically created. For a more advanced configuration OfficeMaster Gate configuration software is required, which can be installed on any PC.

3.2.4. Testing Media Gateway Routing for OfficeMaster SBA

The PSTN connection can be tested via the following dialog. Outgoing calls can if chosen be initialized via the Lync Server functions. Those are contacted via the web interface. Before such a test, the respective users have to be created and configured. Alternatively one can also connect the Gateway directly for test calls.

The test functionality in the lower area controls the Gateway directly, without using the Lync Server Component.

Test outbound call via Target phone number (E Test outbound call	Lync Server 164 format, e.g. +123456789) Result:	
Test PSTN gateway	vav 🔘 external gateway (IP-Ad	dress)
Test outbound call		
Target phone number (e.g. 123456789):		
Caller phone number (optional):		
Test outbound call	Result:	
Test inbound call		
Test inbound call	Result:	
Cancel test		

Image 3.26: Test of the Configuration via the web interface



3.2.5. Display Event Logs and Syslog File

After starting OfficeMaster SBA Administration via browser and logging in with the adequate credentials (e.g. SBA technician account created for bootstrapping), pressing the *Diagnostics* button on the left side shows information from several sources (Lync server log, Windows event logs and Gateway syslog).

	1	Lync Server	
Туре	Date/Time	Source	Message
Information	1/18/2013 4:59:26 PM	LS Replica Replicator Agent Service	Microsoft Lync Server 2 Status report reason: [
Error	1/18/2013 4:57:23 PM	LS Mediation Server	The Mediation Server s Affected PSTN Trunk Se mgbdl120.lync2013.lar Cause: MEDIATIONSER Resolution: If the failure is MEDIAT
			The Trunk peer cannot The Trunk peer, mgbdl: DNS Resolution Failure Exception: Microsoft.R
4			•

Image 3.27: SBA Log files

3.2.6. System Status

Clicking the *Status* button shows the administration page, where Lync related services can be started or stopped. The status of the service can be queried.

Replicator Agent 🥥 🍃 📕	PS	TN interfac	e states	
Logging Agent 🥥 ≽ 📕		Layer 1	Layer 2	Calls
Front-End Server 🥥 🍃 📕	PRI 1		0	0 🕤
Mediation Server 🥥 🍃 📕	PRI 2	Ö	Ö	0 🍙
Refresh service states	BRI 1	Ö	0	0 📦
Display status of replication	BRI 2	0	0	0 🌍
	BRI 3			0 🍘
Display certificate status	BRI 4	0	0	0 🕥
Reboot	FXS 1	0	0	0 🕤
Lync Server Centralized Logging	FXS 2	Ö	0	0 🕤
Running	FXS 3	0	0	0 🕡
Get Service RTCCLSAGT executed	FXS 4	Õ	Õ	0 🕥
Running	Refr	resh states	contir	nuous

Image 3.28: Performance status Master Gateway Board



Table 3.3: The Status of the PSTN ports are displayed via colored buttons

grey	not used
yellow	idle
green	Layer (1 or 2) active/activated
red	Layer (1 or 2) inactive/disabled

3.3. OfficeMaster Gate and Lync Server 2010

This chapter documents the necessary configurations for using the phone functions of Microsoft Lync Server 2010 and OfficeMaster Gate. For reasons of comprehension, the connection via TCP and RTP (also unencrypted) is explained first. The configuration of an encrypted connection via TLS and SRTP is explained afterwards.

3.3.1. Connection via TCP/RTP (not encrypted)

For the complete phone function with external participants (*Enterprise Voice*), a few configuration steps have to be carried out on the Lync side.

► Topology

Before any Lync components can be installed or used, they have to be made known in the topology. For this, *Lync Server Topology Builder* was designed, with which all servers and server rolls but also components like a PSTN gateway are laid out. The gateway object is created at the respective site in the folder *PSTN gateways* via the function *New IP/PSTN Gateway...*.

Define New IP/PSTN Gateway	X
Gateway FQDN or IP Address *	
officemastergate.rtm.lan	
Listening port for IP/PSTN gateway: *	
5066	
Sip Transport Protocol: • TCP	
C TLS	
Help	OK Cancel

Image 3.29: Setting Gateway in Topology

In the first step, an unencrypted configuration is set up, also via TCP. As target port, we suggest using 5066.





Note! Has in the gateway the normal value of 5060 been used for TCP, 5060 must be used here as well. Alternatively the suggested value 5066 can be used. In that case the VoIP parameter for TCP in the gateway configuration has to be changed as well. The definition of target ports in both directions (Lync --> Gateway / Gateway --> Lync) is independent from one another. Important is only, that both sides are set up with fitting configurations.

Usually, the Lync-Mediation Server will use the port 5068 for incoming TCP connections and the port 5067 for incoming TLS connections. Those ports are therefore to be set up in the rules of the gateway for incoming calls. For the other way, so towards the gateway, there are two possible ways:

- Use of the SIP standard port (5060 for TCP and 5061 for TLS)
- Use of the suggestions of the Topology Builder (5066 for TCP and 5067 for TLS)

Whatever was is chosen, it is important that in any given case, the settings of the Topology Builder and those of the VoIP parameter in the gateway are consistent with each other.

This will have laid out the gateway, but the assignment to a Mediation Pool is still missing. This is why the Topology Builder will still show an icon at the top left side, indication that the configuration is yet to be completed. A click on Lync Server 2010 (top) will show applicable details under *Topology validation errors* in the main window:

•	ServiceId "PstnGateway:officemastergate.rtm.lan" requires a
	dependency on a service of role MediationServer with usage Default

Image 3.30: Topology builder error message

Under "Mediation pools" the preferred server is selected and editing activated by pressing *Edit Properties*…. There, the gateway is selected and added to the server.

	Mediation Server PSTN gateway		
	Listening ports: * TLS: 5067 TCP:	5068	
	Enable TCP port		
C	The TCP port of this Mediation Server must	be enabled because a	TCP gateway depends
i	The following gateways are not associated v Server.	with any Mediation Serv	ver. Click Add to assoc
	Gateway	Site	
	officemastergate.rtm.lan	Central Site Teltow	Add
	1		

Image 3.31: Mediation Pools

The ports that the Mediation Server will accept incoming connections are also selected here. These, contrary to common belief, do not have to be identical to the ports at the gateway side. Important is solely, that the respective side addresses the right ports of the other side. The Lync side was just configured when the gateway was set up, the gateway side will be explained further down where the advanced gateway configuration mode is explained. In the simple mode, that the ports shown are automatically used as targets.

After every change in settings, the Topology has to be published by pressing Publish... . Afterwards, in the Lync Control Panel under Topology it can be checked whether or not the changes have been replicated by every server.



Dial Plan

Another important part of telephony is an appropriate Dial Plan. Dial Plans can very easily be set up and configured via the "*Lync Server Control Panel*". A standard Dial Plan called *Global* exists from the start and cannot be deleted either. Has nothing contrary been configured, this is true for every user.

The Dial Plan mainly is a collection of normalizing rules for phone numbers. These rules are responsible for making it possible, that the user can call phone numbers in the familiar way, independent from for example his location. The result of normalizing should always be a phone number in the E.164 format, as that is what is used as standard in Lync. Every site should have its own dial plan, as the rules are highly dependent on local circumstances.

Example 3.5.

(E.164-Number: +498931769876)

+49 = Germany

89 = Prefix Munich

3176 = participant number (Microsoft)

9876 = extension

»End of example

The format has to be exactly like the example, no spaces or separators may be used. Normalizing rules usually are configured for:

- local calls
- long-distance calls
- international calls
- internal calls
- emergency calls

For all those cases, E.164 numbers should be the result. These then are automatically recognized by Lync and otherwise redirected to the appropriate gateway. There, through the use of additional rules, they are adjusted to the requirements of the existing telephone infrastructure.



The example shows a normalizing rule for long-distance calls. Fundamentally, the setting up of a rule is supported by a graphic interface, which helps to set up the rule correctly. More complex formulas will have to be built manually though.

Build a Normalizatio Fill in the fields that you clicking Edit.	on Rule want to use, or create the rule	manually by
Starting digits:		
0		
Length:		
At least	▼ 6	
Digits to remove:		
1		
Digits to add:		
+49		
Pattern to match:*		
^0(\d{4}\d+)\$		
Translation rule:*		
+49\$1		

Image 3.32: Building a normalization rule

This rule is activated for all numbers that start with a 0 and are in total 6 digits long. One digit (the leading 0) is then eliminated and the numeric sequence +49 is added at the beginning. This changes 0301234567 into +49301234567 and therefore the required the E.164 format. All other rules need to be built in the same way. Mind that the rules are processed from the top to the bottom, until a match has been found.

A rule for international calls could be constructed similarly (Difference: two leading 00's, those are eliminated). This rule should be located above the long-distance rule, as the long distance rule would also be triggered because of the first 0. That would lead to the number 0043198765 being converted into the wrong number +49043198765 instead of +43198765. Alternatively, the long-distance calls rule could also be constructed that way, that not only the first digit has to be a 0, but also that the second digit cannot be a 0 as well ("Starting digits" would then be 0[1-9]).

► Routing

Lastly, it has to be secured that outgoing calls are directed via the configured gateway. For this, a connection will have to be made between the *PSTN Usage*, meaning the call classes like internal or local, the *Voice Policy* assigned to the users and the *Route*, meaning the path to the gateway.

This process will not be explained here, as there is a detailed explanation by Microsoft available. This mechanism allows for a flexible definition of calling allowances as well as Least Cost Routing.



For example, the following settings should be used:

► Lync server settings

Dial Plan	Voice Policy	Route	PSTN Usage	Trunk Con	figuration Te
Create v	oice routing tes	st case info	rmation		
					م
+ New	🔹 🧪 Edit 🔻	Action 1	Commit	•	
Nam	e		Scope	State	PSTN usage
G	lobal		Global	Committed	Internal, Local

Image 3.33: Voice Policy:



PSTN Usage Dial Plan Voice Policy Route Trunk Configuration Create voice routing test case information Edit 🔻 Action **T** Commit ***** Name . State Routes Polici Internal Committed LocalRoute Global Local Committed LocalRoute Global

Image 3.35: PSTN Usage



In *Route*, enter the pattern **^.*\$**. This way, the pattern is true for any calling number. (^ = match from the first sign on, Dot = followed by any sign, Asterisk = any number of repetitions).

► User settings for Lync telephony

In order to be able to make external calls, the user needs to be activated for *Enterprise Voice*. Furthermore, every user needs a phone number in E.164 format:

Те	elephony:		
E	Enterprise Voice 💌		
	Line URI:		
	tel:+493328555346		
	Dial plan policy:		
	<automatic></automatic>		
	Voice policy:		
	<automatic></automatic>		

Image 3.36: User settings

If the user wants to sign in on a Lync phone via dial through, this dial through has to be additionally and separately configured:

Line URI:
tel:+493328555346;ext=346
Image 3.37: Line URI

▶ In the Topology Builder of the Microsoft Lync Server, the gateway is defined

Define New IP/PSTN Gateway	×
Gateway FQDN or IP Address *	
192.168.1.46	
Listening port for IP/PSTN gateway: *	
5066	
Sip Transport Protocol: TCP TLS	
Help OK	Cancel

Image 3.38: Adding a Gateway in the Topology Builder

The Topology Builder also has an overview, were the ports are listed on which the mediation server accepts incoming calls. For this, TCP has to be activated.



Mediation Server PSTN g	ateway
TLS listening port:	5067
TCP listening port:	5068

Image 3.39: Ports for incoming calls

Settings for OfficeMaster Gate

In the OfficeMaster Gate configuration program, (Start> Programs> OfficeMaster Gate configuration) ports are configured via Edit> VoIP parameters. The values should be the same as shown here (the ports can vary in the way described earlier on).

📲 VoIP Parameters				×
Properties				
Note: The settings below should only be ch the default settings.	anged in special c	ircumstances. Generally, it is re	commended that you use	
Send T.38 re-INVITE (MS Exchange 2007)		Invite Timeout	60 sec ≑	
Voice Activity Detection	\checkmark	Invite Failover Timeout	5 sec ≑	
Packet Time	20 🔻 ms	Trving Timeout	60 sec	
Echo Canceller		Codecs		
Early Media		Ť	G.711a (a-law)	
Early Progress		±	⊡G./TTu (u-law)	
Always RTP On Ringing			roco 🔺	-
PRACK	supported 🔻	SIP TCP/UDP port	5060 -	
SRTP	supported 🔻	SIP TLS port	5061 ≑	
'phone-context' in INVITE FROM		Ringback Country	49	
'phone-context' in INVITE TO		RingBack Tone to ISDN		
Send 'user=phone' in FROM		RingBack Tone to RTP		
Send 'user=phone' in TO		Ignore PI On Ringing		
Do not send Alert		Ignore PI On Progress		-
Send only one Alert	\checkmark	Exchange 2010 Fax Mailhost		4
Do not send ISDN progress		Local SIP domain		
Keep Ringing on TNA		Hostname for TLS		
Options Interval (0=disabled)	0 sec 🖨	Verify trusted caller IP		
Use 'TO'-Header for routing		Preferred Ip-Mode	IPv4 🔻	
		Additional Parameters		
Restore Defaults		[OK Cancel	

Image 3.40: Configuration of the VoIP-Parameters

The *Operation Mode* of the gateway has to be set to *Gateway/mixed* and the *Configuration Mode* has to be set to *basic*. (Both options can be found at Edit> Operation Mode and Edit> Configuration Mode respectively.



Note! It is advised to at first use the basic configuration mode as this will create a first standard rule base which can be used as a starting point in the advanced mode.

Number of Channels to	o Use		
Outbound	30 -		of Total 30 📑
Inbound	30 -		
ISDN Connection			
Туре	Point-to-Point (DID)	QSIG 🕅	Onboard Termination ${igsackinglesized}$
	C Point-to-Multipoint (MSN)		
Dial Prefix	0		
Base Number			
Accept Call after	3 🕂 DID Digits		
Remote Gateway			
Type	Microsoft Lync Server 2010		IP Address
	Office Communications Server 2007 (R2)		lync.rtm.lan
	C Exchange Server 2007/2010 UM		
Country Code	49		
Base Number	+493328455		
	International telephone number without extension in E. 164 format, for example +493328455		

Image 3.41: Linking Lync 2010 in basic mode

Should, for the manipulation of calling numbers, more rules be needed, then the *Configuration Mode* can be set to *Advanced*. A test of the rules is also possible offline, by simply pressing the *Test* button.

3.3.2. Configuring TLS/SRTP

► Time Settings

For the use of certificates it is important, that the internal clock is as accurate as possible. For this, a NTP-Server should be configured. The necessary settings can be found under Edit-> Time Settings

📑 Time Settings	×
Date: 28.04.2017 ~	
Time: 14:09:48	
Time zone: Berlin (DE)	•
NTP Server:	
OK Cancel	

Image 3.42: Time Settings



► Adjusting in the Topology

In order to process the communication between gateway and Lync Server via encrypted TLS, a few changes have to be made in comparison to those in the Connection via TCP/ RTP chapter.

First, the *topology* in the gateway configuration has to be fixed with the Topology Builder:

Define New IP/PSTN Gateway	×
Gateway FQDN or IP Address *	
officemastergate.rtm.lan	
Listening port for IP/PSTN gateway: *	
5067	
Sip Transport Protocol:	
TLS	
Help	OK Cancel

Image 3.43: Configuring Gateway for TLS

Afterwards, the changed Topology has to be published.

► Adjustments in the Gateway

First off, the gateway configuration has to be set to advanced mode. There, the rule for incoming calls is adjusted:

E Call Processing		×
Properties		
General		- 1
Display Name	Inbound Rule	
Туре	Routing -	
Match and Replace		-
Pre-Check Number List	<not specified=""> ~</not>	
	Treat as negative lookup list	
То	Match (.*) Replace +493328455\1	
From	Match (.*) Replace \2	
P-Asserted-Id (PAI)	Match (,*) Replace \3	
Diversion	Match (.*) Replace \4	
Fax Detection		-
Detection timeout	15 🜲 seconds 🛛 Fax Routing	
Fax CSID	•	
Destination		_
Mode	SIP Multiple Destinations	
Host	lync.rtm.lan	
Protocol	TLS Port 5067	
Add. Parameters		

Image 3.44: Incoming rules for TLS



Additionally, a certificate has to be requested and installed for the gateway. The base certificate of the providing certification office has to also be copied into the gateway.

Via Edit > Certificates> Create, a certificate request is created:

Attributes	
Common Name*:	officemastergate.rtm.lan
E-mail Address:	
Country Name:	
State or Province:	
Locality Name:	
Organization Name:	
Organization Unit:	
Subject Alternate Name	25:
RSA key length:	2048 🔻 bits
Indicates required attril	bute

Image 3.45: Requesting Certificate

Important to note is that the *Common Name* has to be identical to the name of the gateway in the DNS! All other fields can be left empty, unless the certification office requires those in order to issue a certificate.

The certificate request can afterwards be taken out of the clipboard and handed into the certification office:

opy the follwing	g certificate r	equest and :	submit it to y	our Certificaty	Authority
BEGIN	CERTIFIC	ATE REOUE	ST		^
MIICaDCCAVA	CAOAwizE	hMB8GA1UE	AxMYb2Zm	aWN1bWFzdGV	JvZ2F
MIIBIjANBok	ahkiG9w0	BAOEFAAOC	AOSAMIIB	CgKCAOEA1Pi	izIHt
J2INOYoLmgA	MIUWGoFp	oKfGaFA29	aVGtBDV+	sdDz1V/B2N0	COs2+
MGoxOg3g9Fa	LOxLigAU	KX8mmVpVb	9WG3+SBe	ECRPtnUu42E	36r1K
R1vLhDXU698	0+uh3tiv	uogvfW+3c	KaJf5Y3v	mUebzJYvtOF	(5a83)
foWODfiiK8Y	IRXeBbX2	D34UNBoz1	nIo/Gui8	avW8UOsvSZ2	2Pz9p
mk81Rc4wA2	2gigrf0f	vdoIasHxe	Aed3iZkT	vG201OukFM1	IXoKa
WIDAOABoAA	WDOYJKoZ	IhvcNAOEE	BOADggEB	ADYFOIDAGD	ShMGT
15IKRpN8IFC	bovA35vW	/5Zxuae/J	ibAMvMRS	kJvm9WrPv4J	JaVib
v2GnzGTveoA	OMagnY1S	Jv9EzHaLC	nsKJ11Rb	Rna8A13wRv5	51ras
Kp2MgzveuI	3IOSalYf	7WiNgvx0I	JaW2g1TH	VXEHrVHEiE	Jebwd 🗸
	~ -				

Image 3.46: Certificate Request

With a Windows certification office, these are the steps that need to be taken:

- Selection of the certification administration in the browser (".../certsrv")
- Certificate Request



- Advanced Certificate Request
- base-64-encoded...
- Copy the request from the clipboard into Saved Request
- choose template Web Server
- "Submit >"
- Download certificate

The locally saved certificate is afterwards loaded into the gateway by pressing *Import...* in the *Install Certificate* section.

Now the certificate of the certification office has to be saved locally by pressing *Download a CA certificate...* and *Download CA certificate*. After that, the certificate is copied into the gateway by pressing *Import...* in *Root CA Certificate*.

ertificates		?
Settinas		
To for a hundring		
Infrastructure		
State:	•	
Request:	No pending request	
Certificate:	Installed	
Root CA:	Installed	
-Certificate Reque	st	
The first step nee this request to a	ded to get a server certificate is creating a r Certificate Authority.	equest. Submit
	Create Display,.,,	Cancel,
-Install Certificate		
The Certificate A contains your put	uthority will generate a certificate response f vlic key and is digitally signed.	île, which
	ļ	Import
-Root CA Certifica	e	
To complete the c certification auth	ertificate installation you need to install a tru ority (CA) certificate.	isted root
	Verify	Import

Image 3.47: Imported Certificate



With this, the setting up of the SIP encryption via TLS is completed. By pressing *Verify...*, it can be tested if a TLS connection can be set up to the target.



Note! If the same gateway is addressed by multiple Mediation Servers, it has to be defined in the Topology under multiple DNS names (all with the same IP address). To further use TLS in this case, the additional names have to be stated as *Subject Alternate Names* when requesting a certificate.

3.4. OfficeMaster Gate and Exchange Unified Messaging



Note! If Exchange UM is used as a voice mail system with OCS or Lync, no additional configuration of the gateway for Exchange is needed. The systems mentioned above independently set up the connection to the UM role.

Shall an ordinary telecommunications installation be connected to Exchange UM via OfficeMaster Gate, begin the configuration in the basic mode of the configuration program (see basic configuration mode).

With this, the gateway should already be ready for use. Further information can be found under *Functionality* and *Connection*.

3.4.1. Receiving Fax with Microsoft Exchange 2010

Introduction

Microsoft Exchange Server 2007 with the Unified Messaging Role provides the possibility to receive fax, without having to use third-party software. This fax function is based on the voice mail system, meaning that incoming fax calls need to reach the Voice-Mailbox of the respective user first. After successfully having set up the connection, the protocol has to be changed from language to T.38 Fax to enable fax receiving. The VoIP gateway in use has to support T.38 for this function.

Fax is not part of Exchange UM, additionally some useful features for fax like ECM (error correction) are missing. Nevertheless, this solution has proven to be a useful extension to the Unified Messaging-Software of a wide range of users.

Receiving Fax with Exchange 2010 UM

With Exchange 2010, Microsoft decided to completely leave fax communication to third party software, quite like in their Exchange 2007 versions. In order to enable users to still receive fax messages, Microsoft built in the option of switching between Voice-Mailbox and fax. This is realized via separate fax solutions, which receive the fax via T.38 and then, like in Exchange 2007, send an email with TIFF attachment to the mailbox of the user.



Concept of the Partner Fax solution for Exchange 2010

The following graphic shows, how incoming fax messages are processed with Exchange 2010 in combination with a partner solution (T.38 based fax server):



Image 3.48: Receiving Fax with Exchange 2010

Internal Fax solution vs external provider

Partner fax solutions can either be installed directly at the customer or provided by an external third-party provider. If all fax features including dispatching are required, an installation on site is usually the best way to go. The applied UM-Gateway should for this be compatible with this fax solution.

With external fax solutions, usually only the receiving of fax solutions (which is enough for most users especially in the USA) is supported. In this case T.38 fax data is routed via the normal internet connection, which results in lowered service quality (rate of successful fax messages). The translation of T.38 to connection with Jitter and packet-loss on the internet as well as several different sending fax devices can lead to a decrease in the success rate from 100% (with direct TDM/ISDN connection) down to 90%.

OfficeMaster Gate - UM Gateway with in-built fax solution

OfficeMaster Gate, the Ferrari electronic UM/UC Gateway for Exchange UM and OCS 2007 (R2), provides a unique solution for this. Media gateway and partner fax solution are here combined in one device!



Incoming fax connections, that reach the Exchange UM-Mailbox, are directed back to the Gateway, which still holds the PSTN connection. OfficeMaster Gate receives the fax directly via the T.30 fax protocol (without converting it to T.38) and forwards it after successfully receiving it to the mailbox of the user.



Image 3.49: Integrated fax income in OfficeMaster Gate

This provides several advantages for the user:

- No separate fax solution of a partner of service provider is needed.
- The success rate is very high, due to the fax message being directly received via the T.30 protocol at the ISDN port.
- This function is provided without further cost with every OfficeMaster Gate that supports fax.

Configuration of fax with Exchange 2010 and OfficeMaster Gate

Only a few simple steps are required in order to configure the function to receive fax via Exchange 2010 and OfficeMaster Gate:

- Fax has to be activated in the dial plan, the mailbox policies and the mailboxes of Exchange 2010. Additionally, the *Partner Fax Server URI* has to be declared in the mailbox policies.
- The address of the Hub-Transport Servers has to be configured with the port of the reception connector at OfficeMaster Gate.



Exchange 2010 configuration steps

The settings can either be configured via the Exchange Management Shell or via the Exchange Management console. Experienced administrators will know of the steps required in the Shell. The settings of the console are explained in the following.

To enable fax in a dial plan, check the appropriate box in the *General* tab. In the linked mailbox policy, select *Allow inbound faxes* and declare the SIP URI of OfficeMaster Gate:

ow Properties					
Settings General	Dialing Ru Subscriber Acc	ule Groups cess	Dial Codes	aling Res	trictions Features
Associated UM s	ervers:	MSX			
Associated UM IF	^p gateways:	OmGate, C	CS		
URI type:		SIP URI			
Number of digits i	n the extension:	3			
Modified:	receive faxes	Freitag, 28	. August 2009	22:33:14	1
Modified: Allow users to Allow users to VoIP security:	receive faxes configure call an	Freitag, 28 swering rules Secur	August 2009	22:33:14	
Modified: Allow users to Allow users to VoIP security:	receive faxes configure call an:	Freitag, 28 swering rules Secur	August 2009 ed	22:33:14	
Modified: Allow users to Allow users to VoIP security:) receive faxes) configure call an:	Freitag, 28 swering rules Secur	August 2009	22:33:14	•
Modified: Allow users to Allow users to VoIP security:	o receive faxes o configure call an:	Freitag, 28 swering rules Secur	August 2009	22:33:14	
Modified: Allow users to Allow users to VoIP security:	o receive faxes o configure call an:	Freitag, 28 swering rules Secur	ed	22:33:14	
Modified: Allow users to Allow users to VoIP security:) receive faxes) configure call an:	Freitag, 28 swering rules Secur	ed	22:33:14	•

Image 3.50: Activating fax in the dial plan



In the connected mailbox rules, *Allow inbound faxes* has to be selected and the SIP URI of OfficeMaster Gate has to be set.

eltow Default Policy Properties						
Gener	General Message Text PIN Policies Dialing Restrictions Protected Voice Mail					
		L				
2	teltow Default Policy					
		L				
As	sociated UM dial plan: teltow	L				
Mo	odified: Donnerstag, 10. September 2009 23:02:06					
Ma	aximum greeting duration (minutes):					
☑	Allow missed call notifications					
~	Allow Message Waiting Indicator	L				
☑	Allow inbound faxes					
	Partner fax server URI:					
	sip:omgate.e14tap.lan:5061,transport=tls	L				
	(Examples: sip.fax3.eng.contoso.com:5060;transport=tcp, sip:rfx.it.litware.com:5061;transport=tls)					
☑	Allow Voice Mail Preview					
	Allow Outlook Voice Access					
☑	Allow Play on Phone					
◄	Allow users to configure call answering rules	L				
5	OK Cancel Apply Help					

Image 3.51: Allowing incoming fax

As addition to the address of OfficeMaster Gate (Partner fax server URI), **5061; transport=tis** has to be added for a saved dial plan, **5060;transport=tcp** for an unsaved dial plan. Saved dial plans are required, should the policy also be used for OCS and/or Lync.

Additionally, a separate reception connector has to be set up, in order to accept fax messages which are received via SMTP of the partner fax solution (OfficeMaster Gate). The connector has to allow that mails, send from the IP of the OfficeMaster Gate via an idle port (for example 2525), are received.

The following additional settings have to be made for this connector:

UM Partner Properties X					
General Network	Authentication Permission Groups				
Specify which security mechanisms are available for incoming connections Iransport Layer Security (TLS) Enable Domain Security (Mutual Auth TLS)					
Bagic Authentication Offer Basic authentication only after starting TLS					
 Exchange Server authentication Integrated Windows authentication Extemally Secured (for example, with IPsec) 					

Image 3.52: Connector Settings - Authentication





Image 3.53: Connector Settings - Permission Groups

OfficeMaster Gate Settings

Incoming calls are processed by OfficeMaster Gate via one or more rules. *Fax Detection* has to be activated, so that OfficeMaster Gate can switch between receiving faxes and incoming voice mails:

📑 Call Pro	cessing Inbound				? X
Propertie	es				
6	Display Name				
	Name	Exchar	nge 2010 Fax ext	ensions	
	Match and Replace				
	Called Party Number	Match	3()	Replace	999
	Calling Party Number	Match	(.*)	Replace	\2
	Calling Party Number 2	Match	(.*)	Replace	\3
	Redirected Number	Match	(.*)	Replace	9\1
	V Fax Detection				
	Detection timeout	15 🍦	seconds		Fax Routing 📃
	Fax CSID				
	Destination				
	Mode	SIP	•	Multiple	e Destinations
	Host	msx.e	14tap.lan		
Protocol			✓ Port 506	51 🌲	
	Add. Parameters				
Proces	Process Next Rules OK Cancel				

Image 3.54: Rules in OfficeMaster Gate



According to the dial plan, *TLS/5061* or *TCP/5060* has to be selected. Under Edit > VoIP Parameters..., FQDN and port are inserted in the Exchange 2010 Fax Mail-host box

∎ ë V	VoIP Parameters ? X						
F	Properties Note: The settings below should o you use the default settings.	nly be changed in	special circumstances. Gener	ally, it is recommended that			
S	Send T.38 re-INVITE		Invite Timeout	60 sec 🌻			
	/oice Activity Detection		Invite Failover Timeout	5 sec 🌲			
F	Packet Time	20 👻 ms	Codecs				
E	Echo Canceller		Ť	G.711u (u-law)			
E	Early Media	\checkmark		V G./11a (a-law)			
4	Always RTP On Ringing	\checkmark	· · · · · ·				
F	PRACK	supported 👻	Ringback Country	49			
S	SRTP	supported 👻	RingBack Tone to ISDN				
1	phone-context' in INVITE FROM		RingBack Tone to RTP Ignore PI On Ringing				
1	phone-context' in INVITE TO		Ignore PI On Progress				
s	Send 'user=phone' in FROM		Exchange 2010 Fax Mailhos	t msx.e14tap.lan:2525			
s	Send 'user=phone' in TO						
	Do not send Alert						
S	Send only one Alert	\checkmark	Additional Parameters				
	Do not send ISDN progress						
Re	estore Defaults			OK Cancel			

Image 3.55: Setting Exchange Mail-host in OfficeMaster Gate



When using a secured dial plan, OfficeMaster Gate has to be prepared for the use of TLS. For this, a certificate has to be requested and installed. Besides that, the certificate of the certification office has to be loaded in as well. This is done under Edit > Certificate....

Certificates		;			
Settings					
Infrastructure					
State:	۲				
Request:	No pending request				
Certificate:	Not Installed	view			
Root CA:	Not Installed	view			
Certificate Reque	st				
The first step nee this request to a	eded to get a server certificate is creati Certificate Authority.	ing a request. Submit			
	Create Display	. Cancel			
Install Certificate					
The Certificate A contains your pu	The Certificate Authority will generate a certificate response file, which contains your public key and is digitally signed.				
		Import			
Root CA Certifica	te				
To complete the or certification auth	To complete the certificate installation you need to install a trusted root certification authority (CA) certificate.				
	Verify	Import			
		Close			

Image 3.56: Inserting certificate in OfficeMaster Gate

Exchange Fax in full functionality with OfficeMaster for Exchange

The solution introduced here will only support the receiving of fax messages, which for many users, especially in Europe, will not be enough. Many companies still send fax messages as an integral part of business communication.

From 1990 on, starting with MS-DOS and Windows 2.11 as well as MS-Mail and MS Exchange 4.0, Ferrari electronic AG has been a provider of fax solutions.

"OfficeMaster for Exchange" is one of the leading products and supports Exchange 2000, 2003, 2007 and 2010. It includes a long range of functions and can be incorporated into all major applications (CRM, ERP, DMS, etc.) Detailed information can be found under http://www.officemaster.de



3.5. Drop & Insert – OfficeMaster Gate between Trunk and PBX

Base scenario: When migrating to Microsoft Skype for Business/Lync, the previous PBX is often used parallel to the new Lync environment. This can be realized in two ways:

- 1. The Gateway is set up behind the PBX for this, additional ISDN ports as well as changes to the PBX are required.
- 2. Installation of the Gateway between the Trunk and the PBX ("Drop & Insert") no changes need to be made on the PBX. Also enables the automatic distribution of incoming calls to Lync resp. PBX (requires additional Windows Software to automatically recognize migrated users).

In order to enable communication between all users, six different paths need to be configured.

3.5.1. Inbound routing

Trunk > OMG > PBX, Connection to the Trunk

An interface of OfficeMaster Gate is connected with the Trunk. This Interface has to be run in *TE mode*. These are the standard settings for ISDN interfaces with OfficeMaster Gate.

ISDN Connection						
Туре	Point-to-Point (DID)	QSIG Onboard Termination				
	O Point-to-Multipoint (MSN)					
ISDN Type of Number, N	ISDN Type of Number, Mapping from/to E. 164					
Type of number	📑 Advanced Connection Parar	neters ×				
International						
National	Properties Customize					
Subscriber	Dial Timeout	0 sec 🜲				
Apply to	Caller Name Display Mode	Off 👻				
	Point-to-Point Options	No auto-activation				
		Network Termination mode				
	Costs	Auto				
	Require CRC4 in Layer 1					
Add. Parameters	Reset	OK Cancel				

Image 3.57: Running the interface to the Trunk in TE mode



The rule set has to re-route all incoming calls from the Trunk, respectively all calls incoming on this interface, back to ISDN. For this, a new rule for incoming calls (*Calls from ISDN*) is created with the target ISDN:

	General	
(Tx)	Display Name	#2 PSTN2PBX
	Туре	Routing -
	Match and Replace	
	Pre-Check Number List	<not specified=""></not>
		Treat as negative lookup list
	Called Party Number	Match (.*) Replace #2\1
	Calling Party Number	Match (.*) Replace \2
	Calling Party Number 2	Match (.*) Replace \3
	Redirecting Number	Match (.*) Replace \4
	Fax Detection	
	Detection timeout	15 🗘 seconds Fax Routing
	Fax CSID	
	Destination	
	Mode	ISDN Multiple Destinations
	Host	
	Protocol	TCP 🔻 Port 5060 🜩
	Add. Parameters	
	Parameter Profile	<use global="" settings=""></use>

Image 3.58: Routing Trunk to ISDN

The calls are in most cases supposed to be issued to a defined interface. It is therefore advisable to name the routing rules in relation to their function. In any case it is needed to use a unique combination of characters in front of the call number under *Replace* so that calls can be identified properly.

Linking to the PBX

For the second interface to be connected to the PBX properly, usually a cross ISDN cable as well as the NT mode are needed.

📑 Advanced Con	nection Parameters			×
Properties Cu	istomize			
Dial Timeout	5 sec	* *		
Caller Name Displa	ay Mode Off	•		
Point-to-Point Op	tions 🗌 No a	uto-activation		
	Network	vork Termination mo	de	
Costs				Auto
Require CRC4 in L	.ayer1			
Reset			ОК	Cancel

Image 3.59: Advanced Connection Parameters

Additionally, a timeout has to be set for outbound calls from the PBX to the Trunk.



After the interface has been configured, a rule has to be created that receives re-routed calls from the Trunk and routes them to the PBX. For this, a new rule has to be created under *Calls to ISDN*. The Prefix added in the first interface is needed for recognition. Before routing to the PBX, it has to be removed.

-	General	
(Fx)	Display Name	PSTN2PBX
	Туре	Routing -
	Match and Replace	
	Pre-Check Number List	<not specified=""> ~</not>
		Treat as negative lookup list
	IP Address	~ ·
	Called Party Number	Match #2(.*) Replace \1
	Calling Party Number	Match (.*) Replace \2
	Redirecting Number	Match (.*) Replace \3
	Destination	
	Mode	ISDN 🔻 Multiple Destinations
	Host	
	Protocol	TCP 🔻 Port 5060 🜩
	Add. Parameters	
	Parameter Profile	<use global="" settings=""> 👻</use>

Image 3.60: Receiving calls from the first interface, removing prefix and routing to the PBX

Result

After those settings have been made, all calls from the Trunk are forwarded via OfficeMaster Gate to the PBX.



3.6. Outbound routing

PBX > OfficeMaster Gate > Trunk

The two interfaces are already configured via the steps in section 3.5.1 Seite 69. Now the required rules have to be created.

Linking to the PBX

Under *Calls from ISDN* rules need to be created for calls that are to be taken by the PBX. For this, a new rule has to be created with the target *ISDN*.

📲 Call Pro	ocessing	×
Propertie	s	
	General	
1	Display Name	#1 PBX2PSTN
	Туре	Routing -
	Match and Replace	
	Pre-Check Number List	<not specified=""></not>
		Treat as negative lookup list
	Called Party Number	Match (.*) Replace #1\1
	Calling Party Number	Match (,*) Replace \2
	Calling Party Number 2	Match (.*) Replace \3
	Redirecting Number	Match (.*) Replace \4
	Fax Detection	
	Detection timeout	15 🔹 seconds 🛛 🗛 Routing
	Fax CSID	•
	Destination	
	Mode	ISDN Multiple Destinations
	HOST	
	Protocol	TCP 🔻 Port 5060 🜩
	Add. Parameters	
	Parameter Profile	<use global="" settings=""></use>
Disable	the rule	OK Cancel

Image 3.61: Routing PBX to ISDN


Linking to the Trunk

Here the interface for the trunk is selected and a rule for *Calls to ISDN* is created. The previously added prefix has to be removed.

Properti	es	
	General	
<u>v</u>	Display Name	PBX2PSTN
	Туре	Routing -
	Match and Replace	
	Pre-Check Number List	<not specified=""> ~</not>
		Treat as negative lookup list
	IP Address	~
	Called Party Number	Match #1(.*) Replace \1
	Calling Party Number	Match (,*) Replace \2
	Redirecting Number	Match (.*) Replace \3
	Destination	
	Mode	ISDN 👻 Multiple Destinations
	Host	
	Protocol	TCP 🔻 Port 5060 🜩
	Add. Parameters	
	Parameter Profile	<use global="" settings=""></use>

Image 3.62: Receiving calls from the interface, removing the prefix and routing to the trunk



4. ADVANCED CONFIGURATION

SIP Trunk access VoIP parameter

User manual for administrators | Ferrari electronic AG

Copyright © 2017 Ferrari electronic AG

UNIFIED COMMUNICATIONS www.ferrari-electronic.com



4. Advanced Configuration

4.1. Sign in at a SIP-Trunk

OfficeMaster Gate can alternatively or additionally to the ISDN connection be connected to a SIP-Trunk.

Edit > SIP Trunk Registration opens the login dialog.

SIP Trunk Registration X						
SIP Trunk Registration						
SIP-Domain:	SIPTRUNK1					
Port:	5060 Protocol: UDP -					
User:						
Auth. Username:						
Password:						
Interval:	600 sec 🔹					
SIP Proxy:	Port: 5060 🜩					
	OK Cancel					

Image 4.1: SIP-Trunk login

► SIP Trunk Registration

If this box checked, OfficeMaster Gate will attempt to sign in at the defined SIP-Trunk.

► Host

Enter the IP or Host name provided by the provider.

Port/Protocol

This information is also available from the provider or network administrator.

User/Password

Username and password to sign in with the provider.

► Interval

Set the interval in which REGISTER messages are send to the provider.



Table 4.1: List of supported SIP-Trunks¹

QSC	certified, including Fax	
Telekom	tested and approved	
IP Austria	tested, including Fax	
Vodafone	tested, including Fax	
SIPGate	being tested	
BT	being tested	

4.2. Registering SIP devices

Telephones and other devices can use SIP to register on the OfficeMaster Gate and initiate or take calls. However, as OfficeMaster Gate is no PBX, the device administration can only be carried out on a limited basis.

Click Edit-> SIP device registration to edit basic settings for the respective SIP devices.



Image 4.2: SIP device registration



Note! We endeavour to enhance the list of supported SIP trunks constantly. The SIP devices shown here those available as of April 2017.

You can choose between various registration settings in the subsequent dialogue.





Image 4.3: Possible settings for SIP device registration

Without password (Default)

Any devices can register without the necessity of entering a password.

► Global password

The password entered here affects all SIP registrations to the OfficeMaster Gate.

Disabled

OfficeMaster Gate won't allow any registrations.

4.3. Settings for OfficeMaster SIP2Lync

These functions have to be activated if OfficeMaster SIP2Lync is to be used with OfficeMaster Gate. Licensing in this case is done by the OfficeMaster Gate. Edit > SIP2Lync Settings is therefore only available after the correct extension license has been integrated into OfficeMaster Gate.

	SIP2Lync Settings
Activat	e SIP2Lync
<u>H</u> ost: <u>P</u> rotocol:	TLS Port: 8001
	OK Cancel

Image 4.4: Activating SIP2Lync



► Activate SIP2Lync

By selecting this option, OfficeMaster SIP2Lync can be run with the OfficeMaster Gate in use.

► Host

Enter the IP or Host name of the server on which the OfficeMaster SIP2Lync Service was installed.

► Port/Protocol

Communications port and decision between UDP/TCP

4.4. VoIP Parameter

Edit > VoIP-Parameter allows more detailed settings for the voice processing in the IP network.

3 VoIP Parameters ≻						
Properties						
Note: The settings below should only be d the default settings.	hanged in special c	ircumstances. Generally, it is	recommended that you use			
Send T. 38 re-INVITE (MS Exchange 2007) Voice Activity Detection Packet Time Echo Canceller Early Media Early Progress Always RTP On Ringing PRACK SRTP 'phone-context' in INVITE FROM 'phone-context' in INVITE TO Send 'user =phone' in FROM Send 'user =phone' in TO Do not send Alert Send only one Alert Send only one Alert Do not send ISDN progress Keep Ringing on TNA Options Interval (0=disabled) Use 'TO'-Header for routing	20 ▼ ms 20 ▼ ms 20 ▼ ms 3 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	Invite Timeout Invite Failover Timeout Trying Timeout Codecs SIP TCP/UDP port SIP TCP/UDP port SIP TLS port RingBack Tone to ISDN RingBack Tone to ISDN RingBack Tone to RTP Ignore PI On Ringing Ignore PI On Progress Exchange 20 10 Fax Mailho Local SIP domain Hostname for TLS Verify trusted caller IP Preferred Ip-Mode Additional Parameters	60 sec 5 sec 60 sec			
Restore Defaults			OK Cancel			

Image 4.5: VoIP Parameter settings



Note! This option should usually be left unaltered. Some of the options are not operative in older versions of the firmware.



▶ Left column

► Send T.38 re-INVITE

Activating this option will lead to OfficeMaster Gate initiating the switch to T.38 fax receive. Otherwise this is handled via the Exchange UM server.

► Voice Activity Detection (VAD)

is the option to stop the transmission of voice data during pauses in the conversation in order to save bandwidth ("Silence Suppression"). This can also help to avoid echo in certain situations. More on the topic of echo can be found under in "Appendix B: Echo Canceling" auf Seite iii.

Packet Time

The Packet Time of 20 milliseconds is standard. A change to the Packet Time has no advantages.

► Echo Canceler

The Echo Canceler can in certain situations reduce echo. More on the topic of echo can be found under "Appendix B: Echo Canceling" auf Seite iii.

Early Media

Early Media activates the connect through of the voice channel before the connection is completely established in order to make dialing tones and messages audible. We recommend to activate this.

► Early Progress

If Early Progress activated, outbound calls coming from Lync will via a PROGRESS message with SDP in all cases establish an internal voice connection (RTP) before the call is passed over to the ISDN. Improves the behavior of Early Media in order to prevent clipping. Should be activated.

► Always RTP On Ringing

Establishes the RTP connection even when no in-band information is signaled in ISDN.

► PRACK

Via this element, the confirmation of provisional messages can be activated. It has to be set to *supported* / *required* in combination with Microsoft counterparts.

► SRTP

Controls voice encryption (*disabled, supported, required*). We recommend to set it to *supported*. In that case the encryption is used in cases that the counterpart supports it as well.



▶ 'phone-context' in INVITE FROM/TO

The SIP-Header of an *INVITE* contains in *FROM* respectively *TO* a phone context with the here entered information. The entry user in the description field results in the SIP-Header in the appendix phone-context=user. Not commonly used.

► Send 'user=phone' in FROM/TO

User=phone is included in the INVITE of SIP-URIs when this box is checked.

► Do not send Alert

Is this option activated, no *SIP ALERT* messages are send.

Send only one Alert

Only sends ALERTING once into ISDN even if SIP recognizes RINGING multiple times.

► Do not send ISDN progress

For inbound calls Lync receives a **PROGRESS** message while a connection is established, which then results in a **PROGRESS** message in ISDN. Some PBXs react to this with an error - in those cases this option should be activated.

► Keep Ringing on TNA

With common PBXs, devices also ring for inbound calls when the user is not present. If Lync used without a voice mail system and the user is not logged in on any client, the caller will relatively quickly receive a f**ast busy** notice. Is this option activated, the behavior of a PBX will be simulated.

Options Interval

If this value is unequal to 0, the gateway will regularly send a *SIP OPTIONS* request to all configured destinations to check if the counterpart is available. Does not yield any advantages in regular use and therefore can be left at 0 (=inactive).

Right column

Invite Timeout

Sets the time that is waited for a response after an INVITE.

► Invite Failover Timeout

This time setting defines the time it takes to switch to an alternate target should the first server not respond. This only applies when multiple targets or DNS load balancing are used.



► Trying Timeout

Sets the time that is waited for additional messages after receiving *TRYING*.

► Codecs

Defines with which priority which Codecs are used. At least a-law should be activated in Europe.

► SIP TCP/UDP port

On this port the SIP-Stack expects inbound packages via UDP and TCP. More information can be found in section Connection via TCP/RTP.

► SIP TLS port

Port for incoming TLS packages, default is set to **5061**. If Lync Server used, this port has to be set accordingly in the topology for the gateway.

► RingBack Country

The country code chooses the country specific ring back tone. Common values: 1 (USA), 44 (UK), 49 (Germany and other countries). The country code also directs the properties of the analog interface on the PCIe-FXS card.

► RingBack Tone to ISDN

Internally created ring tone is send to ISDN participants.

► RingBack Tone to RTP

Internally created ring tone is send to VoIP participants.

► Ignore PI on Ringing

Suppresses the evaluation of the "Progress Indicator Information Element" in the SIP message RINGING and the ISDN message ALERTING. Only needed for specific test cases.

► Ignore PI on Progress

Suppresses the evaluation of the *Progress Indicator Information Element* in the ISDN/SIP message PROGRESS. Only needed for specific test cases.

Exchange 2010 Fax Mail host

Address and port, when fax is processed via Exchange 2010. More information can be found under Fax reception with Microsoft Exchange 2010.



► Local SIP domain

A value set here will be used as SIP-Domain for SIP messages. Usually not needed.

► Host name for TLS

Enter the name of the OfficeMaster Gate used in the creation of the certificate.

► Verify trusted caller IP

If this box is checked, only SIP messages from known counterparts are accepted (that also appear as destinations in the rules).

Preferred IP-Mode

Select which network protocol is preferred by OfficeMaster Gate.

Additional Parameters

If requested by the Ferrari electronic support, additional parameters can be set here.



Note! Restore to defaults will reverse all changes.

4.5. ISDN Parameter

Edit > ISDN-Parameters enables the editing of further details for ISDN



Image 4.6: Global ISDN settings

PRI Specification

For use in the USA select T1 (23 usable channels), otherwise leave it at E1 (30 B-channels).



Companding Algorithm

Use u-Law in combination with T1, otherwise use a-Law.

► Type of Number

Defines how Called Party Numbers are qualified if not defined differently by the setting of rules.

► Numbering Plan Identification

Defines the numbering plan for Called Party Numbers.

Clock Master Mode

Set to *Auto*, the hardware will independently select the proper clock source. Set to *manually* will let the user select the priority.

Other options like the Network Termination Mode can be found in the advanced mode of the section ISDN settings.

Type of Number / Numbering Plan Identification

÷.

It can occasionally be useful to set the parameter for TON and NPI differently to the global default. For that, a specific string needs to be added to the respective telephone number, additional to the phone number, This string is constructed as follows:

- for the calling party number: <nx:oy>
- for the called party number: <Mx:Oy>

x is the value of TON, while y is the value of NPI in accordance with the following table.

Table 4.2: Individual values for Type of Number/Numbering Plan Identification in the set of rules

1	Unknown	Unknown	
2 International number		ISDN/telephony	
3	National number		
4	Network specific number	Data numbering plan	
5	Subscriber number	Telex numbering plan	
7	Abbreviated number		
9		National standard numbering plan	
10		Private numbering plan	

Ť.

(individual classification of the calling party number for outbound calls)



📑 Call Pro	ocessing		? ×
Propert	ies		
	General		
2	Display Name	Outgoung calls TON national,	NPI ISDN
	Туре	Routing	
	Match and Replace		
	Pre-Check Number List	<not specified=""></not>	•
	Called Party Number	Match (,*)	Replace 1
	Calling Party Number	Match (,*)	Replace <n3:o>\2</n3:o>
	Redirected Number	Match (.*)	Replace \3
🔲 Disable	e the rule		OK Cancel

Image 4.7: TON/NPI individual per rule

This rule delivers the calling party number as TON:National number, NPI:ISDN/telephony.

4.6. ISDN-SIP Mapping

OfficeMaster Gate as a Mediagateway establishes a connection between two different signaling protocols (SIP resp. ISDN Q.931). At both ends different events and statuses can be registered through status and error codes.

SIP deals with so called Response-Codes while ISDN works with Causes.

Edit > ISDN – SIP Mapping... enables the editing of which codes belong to which side. Usually not needed.

SDN> SIP SIP> ISDN		
Add 😭 Edit		🗙 Remove
ISDN	SIP	1
1 Unallocated number	404 Not found	
2 No route to specified transit net	404 Not found	
3 No route to destination	404 Not found	
17 User busy	486 Busy Here	
18 No user responding	408 Request Timeout	
19 No answer from user (user alert	480 Temporarily Unavailable	
20 Subscriber absent	480 Temporarily Unavailable	
21 Call rejected	403 Forbidden	
	40.0	`

Image 4.8: ISDN/SIP Mapping

Restore Defaults reverts all changes.



4.7. Music on hold

When used as telephony gateway, a music on hold can be integrated. Are no changes made, the default melody will be used.

Music that is to be integrated has to be in the following uncompressed format:

• Mono, 8000Hz, a-Law

🎼 OfficeMaster Gate Configuration - 6.1.3.1102 (10.0.0.185) - 🗆 🗙								
File	Edit	View Tools Help						
٦		Firmware Update Change IP Address	Ctrl+U Ctrl+N	iceM	laster Virtual Gate			
 2 		Operation Mode Configuration Mode Change Settings	Ctrl+S	ateA	ndy1 (s/n: OMGV0044	IMGV00447)		
ý		VolP Parameters SIP Trunk Registration		G 4.0 Firmware Up			are Update	odate
		SIP Device Registration SIP2Lync Settings		int				
		ISDN Parameters ISDN-SIP Mapping Logging		0.0. 5.24 1.0.	185 8.0.0 10	Change	IP Addre	ss
		Firewall/Routing Certificates Manage Licenses		tewa vanc	ay/mixed	Chang	je Settings	s
		Time Settings						
		Music On Hold	•		Disabled			1
	_	Drain Mode	•	•	Default Custom			
					Import Audio File			

Image 4.9: Integrating music on hold



Note! Additional information can be found in the forum of Ferrari electronic AG.



5. APPENDIX

List of abbreviations

Echo canceling

Basics on telephony numbers

User manual for administrators | Ferrari electronic AG

Copyright © 2017 Ferrari electronic AG

UNIFIED COMMUNICATIONS





Appendix A: Telephone number basics

In the following the general functionalities of call routing are described, followed by a short introduction into the regular expressions used in the Syntax. The description of the configuration dialog is followed by examples of use and hints.

A.1. Rule based treatment of inbound calls

The treatment of inbound calls in OfficeMaster Gate is handled via adjustable regular expressions. These regular expressions are filed in tabular format and can be analyzed regarding the run time with the help of an interpreter. This presentation at first will appear complicated to an inexperienced administrator. In time and with the help of the provided examples this should however turn into a highly flexible tool. For every inbound call the following information is processed.

► Called Party Number (CPN)

The CPN is the number the caller dialed, respectively the part of the number that is received by the ISDN port.

► Calling Party Number (CGN1) and Calling2 Party Number (CGN2)

CGN1 and CGN2 include the telephone numbers of the caller. In most cases there will only be one Calling Party Number, the second element then remains empty. The first element can also be empty if the caller does not submit a number at all. CGN1 and CGN2 are for example used together when receiving land line SMS. In this case, CGN1 is the telephone number of the sender while the CGN2 is the telephone number of the SMS center. The analysis of the number included in the CGN2 enables the software to recognize that the call serves the transmission of a SMS.

Redirecting Number (RN)

The RN includes the telephone number that was originally dialed by the caller, for which a redirect had been set up.

Example A.1 From a mobile phone with the telephone number 01520189524 the internal telephone number 947 (dial through of the participant) is dialed; this participant has programmed a call forwarding to the Pilot-ID 999 of the voice mail system. The above described errors supply the values listed in the following table.

CPN	Called Party Number (CPN) is 999 because of call forwarding.	
CGN1	Calling Party Number (CGN1) is the number of the mobile phone	
CGN2	usually empty	
RN	Redirecting Number (RN) is 947, meaning the originally called but fowarded number with which the voice mail system recognizes to which user the call is assigned	

Table A.1: Description of the Example

»End of example



Rules have to be defined on how OfficeMaster Gate is to deal with different types of calls, for example forwarded calls that go directly towards the voice box. For this it is also important how the ISDN port of the PBX on which OfficeMaster Gate is run is configured. S2M connections are in all cases able point-to-point ports with the ability to execute dial through. S0 ports (BRI) have to be divided into point-to-point and multi device ports with MSN (Multiple Subscriber Number).

A.2. Regular expressions

Regular expressions, as common in telephony, are used for the recognition and handling of telephone numbers.

Regular expressions create patterns in form of characters (letters, digits) as well as symbols (special characters with special meaning). In order to for example describe all telephone numbers beginning with 1234 followed by three additional spaces, the expression 1234... is used. The dot resembles any character. Parts of such a pattern can be framed in round brackets. The content of the brackets can be referenced in future replacements - this is done by using n, whereby n defines, which brackets are referenced (1...m). Is a special character to be used as a normal character, a backslash ("\") has to be used as a prefix for this special character.

Example A.2

Lync internally uses E.164 numbers like +493328455854. In order to recognize this number in a pattern (and after that to extract the dial through of the user) the pattern \+493328455(...) has to be set. The replacement \1 accesses the content of the bracket and provides the sender extension number 854. The plus sign has a special meaning in regular expressions (1-n times repetition of the previous character) and therefore needs to be written with a backslash for when it is to be recognized as a normal character. Backslash in this case functions as a so called escape character.

»End of example

Example A.3

For the Called Party Number the pattern 1234(...) is entered which, like in the example, matches all numbers that start with 1234 and continue with three more characters.

For a trunk connection the 1234 would for example be the base number followed by the three character extension. To insert this extension into the field for Redirecting Number, the bracket content is referenced with 1. The 1 refers to the first pair of brackets; are multiple brackets used they are referred to with consecutive numbers.

Areas can be specified instead of digits as well. The expression 1234[1-3] for example refers to all five character numbers that start with 1234 and have the digits one, two or three as a fifth character. The expression in the squared brackets represents exactly one character and is treated as a list. This can be defined as an area or as a list. [124-68-9] for example matches the digits 1,2,4,5,6,8,9.

A star (*) signifies that the previous character can appear any number of times; the expression .* is used very often - the expression means that any arbitrary number can appear any number of times. With (xyz)* the whole expression can be quantified. xyz can in turn stand for either characters or symbols. (12.)* means, that the sequence starting with 12 and any arbitrary number as a third character can occur any number of times.



In order to accept multiple possible strings like for example MSNs, vertical lines have to be used; the pattern (12|13|14) means that either 12, 13 or 14 are accepted.

»End of example

In the advanced configuration, rules for CPN, CGN1, CGN2 and RN are defined that are tested in the defined order of the rule until all four patterns match. The in the rule defined replacement pattern is then applied and the call accepted. With every further incoming digit the set of rules is worked through until a match has been found or the inbound call has been ended.

Example A.4

_all Pro	cessing		<u>Y</u>
Properti	es		
	General		
<u>va</u>	Display Name	New Rule	
	Туре	Routing 💌	
	Match and Replace		
	Pre-Check Number List	<not specified=""></not>	•
	Called Party Number	Match 4553()	Replace 999
	Calling Party Number	Match (.*)	Replace 12
	Calling Party Number 2	Match (.*)	Replace \3
	Redirected Number	Match (.*)	Replace 9\1
	Fax Detection		
	Detection timeout	15 🗧 seconds	Fax Routing
	Fax CSID	+49 3328 455 3\1	

Image A.1: Working with basic regular expressions

This image shows a rule that matches all numbers that start with 4553 followed by two characters; the areas CGN1, CGN2 and RN can be arbitrary, even empty. There are four brackets whose content can be referred to with 1 through 4. After the replacement the CPN receives the 999 (for example a Pilot-ID), CGN1 and CGN2 remain unchanged as they with 2 and 3 are replaced with their original content. The Redirecting Number (RN) now contains a three digit number that starts with 9 and then contains the last two characters of the original Called Party Number. The originally dialed telephone number 455347 then for example changes into the redirecting number 947 which resembles the device number of the participant as well as his EUM address in Exchange 2007/2010). Should during the connection a fax receive be recognized and executed, the sender will receive the entire CSID (Called Subscriber Identification) +49 3328 455 347 including the user's extension number.

»End of example



A.3. Configuration examples

The diverse configuration and application possibilities of OfficeMaster Gate are best explained with practical examples. Aside from standard applications more complex cases are also explained.

Inbound calls multi device connection

PBXs inwards often only provide a multi device connection that is designed for the use of ISDN devices, phones in particular. In most cases 1-10 telephone numbers are supported, in rare cases more than that. This restriction is significant for the Office Communications Server 2007 as it means that the number of telephone participants that are directly reachable from the outside is limited. Exchange 2007 UM can be used in the by Microsoft planed way (use of a Pilot-ID) as this only requires one number.

Example A.5

Table A.2: Exchange 2007/2010 UM on multi device connection

Called Party Number	(100)	\1
Calling Party Number	(.*)	\2
Calling2 Party Number	(.*)	\3
Redirecting Number	(.*)	\4
Fax identifier	+49 30 12345 \4	
Destination	SIP: 10.2.3.4	

This rule causes:

- all calls on the ISDN-Bus are forwarded to the number 100 in Exchange (IP address 10.2.3.4).
- other devices on the same Bus can be targeted via additional numbers (MSNs)
- redirected calls transmit the originally dialed extension via SIP to Exchange so that the respective mail box will answer directly.
- Is a fax receive recognized and executed during the connection, the sender receives the entire CSID (Called Subscriber Number) including the user's extension number.

Additional rules are not needed for this specific case. The configuration can be carried out in basic mode.

»End of example

Inbound calls DID Trunk

More flexibility and applicability is gained through the ability of the connection to handle extensions. This includes:

• Introduction of separate fax extensions for Exchange users (without additional EUM address) by prefixing a digit to the extension or by shifting the range of numbers (example below).



- Addressing of different destinations (multiple Exchange UM Server, Lync Server or OfficeMaster Messaging Server) depending on the dialed extension.
- Correction of telephone numbers, for example clipping of all information except for the extension (for example +49(30)1234947 turns into 947) or completion of the extension to a canonical data representation (for example 947 turns into +49(30)1234947).
- Distribution of the calls by Calling Party Number.

I

Example A.6

In a company three character numbers between 700 and 999 are used for telephony. These are cultivated as EUM addresses in Exchange. For the direct accessibility via fax in Exchange, the prefix 6 is to be added for the telephone extension, meaning that the participant with the device number 845 has the fax extension 6845. The Pilot-ID is 100.

»End of example

Called Party Number	6()	100
Calling Party Number	(.*)	\2
Calling2 Party Number	(.*)	\3
Redirecting Number	(.*)	\1
Fax Recognition	+49 30 1234 6 \1	
Destination	SIP: 10.2.3.4	

Table A.3: Set of rule for "example B.6"

Example A.7

For telephony four character numbers between 9000 and 9999 are used. These are cultivated as EUM addresses in Exchange. For the direct accessibility via fax in Exchange, the range of numbers 8000 through 8999 is to be used, whereby telephone and fax extensions are only different in the first character. The participant with the device number 9451 then has the fax extension 8451. Pilot-ID is 7000.

»End of example

Table A.4: Exchange 2007 UM fax extension in separate area

Called Party Number	8()	7000
Calling Party Number	(.*)	\2
Calling2 Party Number	(.*)	\3
Redirecting Number	(.*)	9\1
Fax Recognition	+49 30 1234 8 \1	



Destination	SIP: 10.2.3.4	

By defining a number of sequential rules, many different ranges can be processed separately. However, it is important to remember that the rules will be checked in the predefined sequence until a rule is found that matches the specifications ("first match" principle). The order of the rules therefore might have to be changed in order to ensure the desired processing.

Example A.8

Five digit extension that start with 61 are to be directed to the OfficeMaster Messaging Server. All other numbers beginning with 6 are to be directed to the Exchange Server. The rule 61(...) therefore has to be placed before the rule 6(....) as it would otherwise never be processed because the other rule would match before that.

»End of example

In the following examples rules are displayed in compact form in order to show the interconnection between rules. One rule is displayed in three columns:

Pattern Replacement Destination

whereby Pattern and Replacement incorporates the four individual boxes (Called Party Number, Calling Party Number, Calling Party Number, Calling Party Number and Redirecting Number) separated by commas.

Example A.9

The rule Exchange 2007 fax extension in a separate area in the earlier example would look as follows:

8(...), (.*), (.*), (.*) 7000, 2, 3, 9 1

SIP: 10.2.3.4

The adjustable fax identifier is left out in this representation. In front of every rule the display name is shown in a separate row.

»End of example

Example A.10 (complex case)

OfficeMaster Gate is connected to the PBX via a cross-connection. The PBX transmits all calls to this connection that start with the digit 3. Exchange 2007 UM is reachable via the Pilot-ID 999. Telephone numbers are in the range from 100 through 299. Exchange 2007 is only to be used for voice mail and Outlook Voice Access, fax and SMS are handled by OfficeMaster for Exchange. Voice mail boxes can be called directly when the device number is complemented by the number 30.

In order to reach users via fax, 31 is used as an extension. For SMS the 32 is used. The numbers are transmitted complete in form of 3XXXX to OfficeMaster. Additionally, an Office Communications Server 2007 is being tested. The users there receive the number 33XXX, whereby XXX resembles their device number. The 33 is not to be transmitted to the Office Communications Server for calls. The Exchange 2007 switchboard, that internally in Exchange has the number 998, is to be reached via 34000. Calls to invalid numbering ranges (34001 through 39999) are redirected to the central voice box with the number 100 where an according message is deposited.



Table A.5: The complete list of rules:

30(),(.*),(.*),(.*)	999,\2,\3,\1	SIP: 10.2.3.4
(3[1-2]),(.*),(.*),(.*)	1, 2, 3, 4	OfficeMaster
33(),(.*),(.*),(.*)	1, 2, 3, 4	SIP: 10.2.3.5
34(000),(.*),(.*),(.*)	998,\2,\3,\4	SIP: 10.2.3.4
3(),(.*),(.*),(.*)	999,\2,\3,100	SIP: 10.2.3.4

By adding additional rules, special treatment for specific numbers respectively numbering ranges can be realized.

»End of example

Outbound calls

While for inbound calls at least one rule is needed, rules for outbound calls are optional. They server the transformation of call information.

Areas of appliance are for example:

- Rules for accessing an outside line
- Replacement of extensions by a central number
- Transformation from canonical data representation to dial-able numbers

Example A.11

In a company certain extension are not to be signaled outward. These numbers are 830, 846 and 852. For calls from these devices the extension 800 is to be transmitted instead. At the same time an accessing of an outside line (number 0) for national numbers is to be executed.

Table A.6: Individual outbound calls with central sender number

Called Party Number	(0\+49)(.*)	00\2
Calling Party Number	(830 846 852)	800
Redirecting Number	(.*)	\4

To realize the accessing of an outside line for all participants, an additional rule has to follow this one.



Appendix

Table A.7: Remaining telephone numbers are signaled

Called Party Number	(0\+49)(.*)	00\2
Calling Party Number	(.*)	\3
Redirecting Number	(.*)	\4

It is important for both rules that the Called Party Number is in brackets. As brackets are numbered consecutively, the Calling Party Number is referenced with \3. A second Calling Party Number is non existent for outbound rules.

»End of example

Example A.12

All employees have mobile phone with numbers beginning with 01521 19582. Is one of those numbers dialed, the suppression of the extension is not to happen.

This means, that an additional rule has to precede the rule in the example above:

Table A.8: Defined mobile numbers see the correct sender telephone number

Called Party Number	(0\+49)(152119582.*)	00\2
Calling Party Number	(.*)	\3
Redirecting Number	(.*)	\4

»End of example

